

<b>DTC</b>	<b>B1653/35</b>	<b>SEAT POSITION SENSOR ASSEMBLY MALFUNCTION</b>
------------	-----------------	--


### CIRCUIT DESCRIPTION

The seat position sensor assembly circuit consists of the airbag ECU assy and the seat position airbag sensor.

DTC B1653 is recorded when a malfunction is detected in the seat position sensor assembly circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1653	<ul style="list-style-type: none"> <li>• When the airbag ECU assy receives a line short signal, open signal, short to ground signal or B+ short signal in the seat position sensor assembly circuit for 2 seconds.</li> <li>• Seat position airbag sensor malfunction</li> <li>• Airbag ECU assy malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Floor wire</li> <li>• Seat position airbag sensor (D seat side)</li> <li>• Airbag ECU assy</li> </ul>

### WIRING DIAGRAM




## INSPECTION PROCEDURE

### CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

- (a) Turn the power switch off.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag ECU Assy.
- (d) Disconnect the connectors from the horn button Assy.
- (e) Disconnect the connectors from the front passenger airbag Assy.
- (f) Disconnect the connector from the front seat airbag Assy LH.
- (g) Disconnect the connector from the front seat airbag Assy RH.
- (h) Disconnect the connector from the curtain shield airbag Assy LH.
- (i) Disconnect the connector from the curtain shield airbag Assy RH.
- (j) Disconnect the connector from the front seat outer belt Assy LH.
- (k) Disconnect the connector from the front seat outer belt Assy RH.

### 1 CHECK DTC



- (a) Connect the connectors to the airbag ECU Assy.
- (b) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the power switch on (IG), and wait for at least 60 seconds.
- (d) Clear the DTCs stored in memory (see page 05-1402).
- (e) Turn the power switch off.
- (f) Turn the power switch on (IG) and wait for at least 60 seconds.
- (g) Check the DTCs (see page 05-1402).

#### OK:

**DTC B1653 is not output.**

#### HINT:

Codes other than code B1653 may be output at this time, but they are not related to this check.

**NG**

**Go to step 2**

**OK**

**USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1397)**

**2 CHECK CONNECTION OF CONNECTORS**

- (a) Turn the power switch off.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the airbag ECU Assy and the seat position airbag sensor.


**OK:**

The connectors are connected.

**NG** → **CONNECT CONNECTORS, THEN GO TO STEP 1**

**OK**

**3 CHECK FLOOR WIRE(OPEN)**



- (a) Disconnect the connectors from the airbag ECU Assy and the seat position airbag sensor.
- (b) Using a service wire, connect S17-1 (VS) and S17-3 (GND) of connector "C".

**NOTICE:**

**Do not forcibly insert a service wire into the terminals of the connector when connecting.**

- (c) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester connection	Condition	Specified condition
A17-9 (LSP+) - A17-17 (LSP-)	Always	Below 1 Ω

**NG** → **REPAIR OR REPLACE FLOOR WIRE**

**OK**

**4 CHECK FLOOR WIRE(SHORT)**



- (a) Disconnect the service wire from connector "C".
- (b) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester connection	Condition	Specified condition
A17-9 (LSP+) - A17-17 (LSP-)	Always	1 MΩ or Higher

**NG** REPAIR OR REPLACE FLOOR WIRE

**OK**

**5 CHECK FLOOR WIRE(TO B+)**




- (a) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (b) Turn the power switch on (IG).
- (c) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
A17-9 (LSP+) - Body ground	Power switch is on (IG)	Below 1 V
A17-17 (LSP-) - Body ground	Power switch is on (IG)	Below 1 V

**NG** REPAIR OR REPLACE FLOOR WIRE

**OK**

**6 CHECK FLOOR WIRE(TO GROUND)**


- Turn the power switch off.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
A17-9 (LSP+) - Body ground	Always	1 MΩ or Higher
A17-17 (LSP-) - Body ground	Always	1 MΩ or Higher

**NG** REPAIR OR REPLACE FLOOR WIRE

**OK**

**7 CHECK SEAT POSITION AIR BAG SENSOR**

- Connect the connectors to the airbag ECU assy.
- Connect the connector to the seat position airbag sensor.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1402).
- Turn the power switch off.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Check the DTCs (see page 05-1402).

**OK:**

**DTC B1653 is not output.**

**HINT:**


Codes other than code B1653 may be output at this time, but they are not related to this check.

**NG** Go to step 8

**OK**

**USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1397)**

## 8 REPLACE SEAT POSITION AIRBAG SENSOR



- (a) Turn the power switch off.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the seat position airbag sensor (see page [60-62](#)).

**HINT:**

Perform the inspection using parts from a normal vehicle when possible.

- (d) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (e) Turn the power switch on (IG), and wait for at least 60 seconds.
- (f) Clear the DTCs stored in memory (see page [05-1402](#)).
- (g) Turn the power switch off.
- (h) Turn the power switch on (IG), and wait for at least 60 seconds.
- (i) Check the DTCs (see page [05-1402](#)).

**OK:**

**DTC B1653 is not output.**

**HINT:**

Codes other than code B1653 may be output at this time, but they are not related to this check.

**NG**

**REPLACE AIR BAG ECU ASSY  
(SEE PAGE [60-54](#))**

**OK**

**END**