


AIR FUEL RATIO SENSOR

COMPONENTS



40 (408, 30)*1
44 (449, 32)*2


AIR FUEL RATIO SENSOR
(for Bank 1 Sensor 1)

EC

N*m (kgf*cm, ft.*lbf) : Specified torque

*1: For use with SST

*2: For use without SST



ON-VEHICLE INSPECTION

1. **CHECK AIR FUEL RATIO COMPENSATION SYSTEM**
 - (a) Connect the intelligent tester to the DLC3.
 - (b) Turn the ignition switch ON.
 - (c) Select the following menu items: Data List / A/F S1 and O2S B1 S2.
 - (d) Warm up the A/F sensor with the engine speed at 2,500 rpm for approximately 2 minutes.
 - (e) Keep the engine speed at 2,500 rpm and confirm that the display of "A/F S1" is as shown in the illustration.

HINT:

- The illustration may slightly differ from the display on the intelligent tester.
 - Only the intelligent tester displays the waveform of the A/F sensor.
- (f) Confirm that the display of "O2S B1 S2" changes between 0 to 1 V with the engine speed at 2,500 rpm.

OK:

The voltage output oscillates more than 8 times in 10 seconds.

NOTICE:

- Perform the check immediately after warming the engine up.
- If the voltage variation could not be verified, warm up the A/F sensor again. If it could not be verified even after warming up the sensor again, check for DTCs (see page [ES-292](#)).

