

DTC	C1297/97	Steering Angle Sensor
------------	-----------------	------------------------------


DESCRIPTION

- The 4WD control ECU determines that the vehicle is turning based on the signals sent from the steering angle sensor.
- The steering angle sensor signal is sent to the 4WD control ECU via the CAN communication system.
- The 4WD control ECU detects the amount of steering wheel movement and performs "slip control at vehicle start up", according to the amount of movement, and "slip control" to secure high turning performance.

TF

DTC No.	DTC Detection Condition	Trouble Area
C1297/97	When voltage of 4WD control ECU IG1 terminal is 9.5 V or more, and steering angle sensor malfunction signal is received.	<ul style="list-style-type: none"> • Steering angle sensor • CAN communication • 4WD control ECU • Wire harness

WIRING DIAGRAM



C128601E02

INSPECTION PROCEDURE

HINT:

Check the condition of each related circuit connector before troubleshooting (see page [IN-37](#)).

1	CHECK FOR DTC
----------	----------------------

- (a) Clear the DTC (see page [TF-16](#)).
- (b) Turn the ignition switch OFF.
- (c) Turn the ignition switch ON again and check that no CAN communication system DTC(s) is output.
- (d) Start the engine.

- (e) Drive the vehicle and turn the steering wheel to the right and left at a speed of 35 km/h (24 mph) and check that no brake control system (steering angle sensor) DTC (C1231/31) is output (see page BC-57).

Result

Result	Proceed to
Neither CAN communication system DTC nor brake control system DTC is out put	A
CAN communication system DTC is output	B
Brake control system (steering angle sensor) DTC (C1231/31) is output	C

TF

HINT:


When DTCs indicating a CAN communication system malfunction are output, repair the CAN communication system before repairing each corresponding sensor.

B REPAIR CIRCUIT INDICATOR OUTPUT CODE (CAN COMMUNICATION SYSTEM)

C REPAIR OR REPLACE CIRCUIT INDICATOR OUTPUT CODE (STEERING ANGLE SENSOR CIRCUIT)

A

2 CHECK WIRE HARNESS (STEERING ANGLE SENSOR - BATTERY)




- (a) Disconnect the E11 sensor connector.
 - (b) Measure the voltage of the wire harness side connector.
- Standard voltage**

Tester Condition	Condition	Specified Condition
E11-1 (IG) - Body ground	Ignition switch ON	10 to 14 V

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

3 CHECK WIRE HARNESS (STEERING ANGLE SENSOR - BODY GROUND)



- (a) Disconnect the E11 sensor connector.
 - (b) Measure the resistance of the wire harness side connector.
- Standard resistance**

Tester Condition	Specified Condition
E11-2 (ESS) - Body ground	Below 1 Ω

Result

Result	Proceed to
OK (When troubleshooting according to PROBLEM SYMPTOMS TABLE)	A
OK (When troubleshooting according to DTC chart)	B
NG	C

TF

B

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

C

REPAIR OR REPLACE HARNESS AND CONNECTOR

A

REPLACE STEERING ANGLE SENSOR