

---

# BODY

## GENERAL MAINTENANCE

### 1. TIGHTEN BOLTS AND NUTS

- (a) Tighten the bolts and nuts on the chassis parts listed below, if necessary.
  - Front axle and suspension
  - Drivetrain
  - Rear axle and suspension
  - Brake system
  - Engine mounting
  - Other chassis parts
- (b) Tighten the bolts and nuts on the body parts listed below, if necessary.
  - Seat belt system
  - Seats
  - Doors and hood
  - Body mountings
  - Fuel tank
  - Exhaust pipe system
  - Other body parts

### 2. CLEAN AIR CONDITIONING FILTER

- (a) Visually inspect the surface of the filter.
- (b) If the filter is contaminated with foreign matter, clean or replace the filter.