


## Sliding Roof ECU Power Source Circuit

### DESCRIPTION

If the sliding function and tilt function do not operate, there may be a malfunction in the sliding roof ECU power source circuit.

### WIRING DIAGRAM



RF

### INSPECTION PROCEDURE

#### 1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER (SLIDING ROOF OPERATION)

- (a) Select the Active Test, use the intelligent tester to generate a control command, and then check that the sliding roof operates normally.

## Sliding roof ECU

Item	Test Details	Diagnostic Note
SLIDE ROOF	Operate sliding roof OPN / DWN OPN / DWN: Sliding roof OPEN / DOWN operation occurs OFF: Sliding roof is not operating	-
SLIDE ROOF	Operate sliding roof CLS / UP CLS / UP: Sliding roof CLOSE / UP operation occurs OFF: Sliding roof is not operating	-

OK:

Sliding roof operates normally.

NG

REPLACE SLIDING ROOF DRIVE GEAR SUB-ASSEMBLY

OK

RF

## 2 INSPECT FUSE (S/ROOF, ECU-IG1)

- (a) Remove the S/ROOF and ECU-IG1 fuses from the instrument panel junction block.  
(b) Measure the resistance of the fuses.

**Standard resistance:**Below 1  $\Omega$ 


NG

REPLACE FUSE

OK

## 3 CHECK WIRE HARNESS (SLIDING ROOF DRIVE GEAR - BODY GROUND)

Wire Harness Side



B130117E02

- (a) Disconnect the P6 drive gear connector.  
(b) Measure the voltage and resistance of the wire harness side connector.

**Standard voltage**

Tester Connection	Condition	Specified Condition
P6-1 (B) - Body ground	Always	10 to 14 V
P6-5 (IG) - Body ground	Ignition switch OFF	Below 1 V
P6-5 (IG) - Body ground	Ignition switch ON	10 to 14 V

**Standard resistance**

Tester Connection	Specified Condition
P6-2 (E) - Body ground	Below 1 $\Omega$

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE SLIDING ROOF DRIVE GEAR SUB-ASSEMBLY