


DISASSEMBLY


1. REMOVE PARK/NEUTRAL POSITION SWITCH ASSEMBLY

(a) Remove the nut, washer and control shaft lever.



(b) Using a screwdriver, pry off the lock plate.


(c) Remove the nut and lock plate.



(d) Remove the 2 bolts and pull out the switch.

2. REMOVE BREATHER PLUG HOSE


(a) Remove the breather plug hose from the transaxle case.



3. REMOVE OIL COOLER OUTLET TUBE ELBOW

(a) Remove the elbow.


(b) Remove the O-ring from the elbow.




4. REMOVE OIL COOLER INLET TUBE ELBOW

(a) Remove the elbow.

(b) Remove the O-ring from the elbow.






5. REMOVE SPEED SENSOR

- (a) Remove the 2 bolts and the 2 speed sensors from the transaxle.


6. REMOVE SPEEDOMETER DRIVEN HOLE COVER SUB-ASSEMBLY

- (a) Remove the bolt and cover.
(b) Remove the O-ring from the cover.




7. REMOVE NO. 1 TRANSAXLE CASE PLUG

- (a) Remove the 4 plugs from the transaxle case.
(b) Remove the 4 O-rings from the 4 plugs.



8. FIX AUTOMATIC TRANSAXLE ASSEMBLY


- (a) Fix the transaxle.




9. REMOVE AUTOMATIC TRANSAXLE OIL PAN SUB-ASSEMBLY

- (a) Remove the 18 bolts, oil pan and gasket.

- (b) Remove the 2 magnets from the oil pan.



**10. INSPECT TRANSMISSION OIL CLEANER MAGNET**

- (a) Remove the magnets and use them to collect any steel chips. Examine the chips and particles in the pan and on the magnet to determine what type of wear has occurred in the transaxle.


Result:

Steel (magnetic):

Wear of the bearing, gear and plate



Brass (non-magnetic):

Wear of the bush


**11. REMOVE VALVE BODY OIL STRAINER ASSEMBLY**

- (a) Remove the 3 bolts and oil strainer.


- (b) Remove the O-ring from the oil strainer.

**12. REMOVE TRANSMISSION WIRE**

- (a) Remove the 7 connectors from the shift solenoid valves.
- (b) Remove the bolt, lock plate and temperature sensor.




- (c) Remove the bolt and transmission wire from the transaxle case.




13. REMOVE TRANSMISSION VALVE BODY ASSEMBLY

- (a) Support the valve body and remove the 17 bolts and valve body.




14. REMOVE NO. 1 GOVERNOR APPLY GASKET

- (a) Remove the gasket from the transaxle case.




15. REMOVE TRANSAXLE CASE 2ND BRAKE GASKET

- (a) Remove the gasket from the transaxle case.




16. REMOVE BRAKE DRUM GASKET

- (a) Remove the gasket from the transaxle case.




17. REMOVE CHECK BALL BODY

- (a) Remove the check ball body and spring from the transaxle case.



18. REMOVE C-3 ACCUMULATOR PISTON

- (a) Remove the spring from the C-3 accumulator piston.





- (b) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the C-3 accumulator piston.

NOTICE:

- Applying compressed air may cause the piston to jump out. When removing the piston, hold it using a waste cloth.
- Take care not to splash ATF when applying compressed air.

- (c) Remove the O-ring from the C-3 accumulator piston.




19. REMOVE REVERSE CLUTCH ACCUMULATOR PISTON


- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the reverse accumulator piston and spring.

NOTICE:

- Applying compressed air may cause the piston to jump out. When removing the piston, hold it using a waste cloth.
- Take care not to splash ATF when applying compressed air.

- (b) Remove the 2 O-rings from the reverse clutch accumulator piston.







20. REMOVE B-3 ACCUMULATOR PISTON

- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the B-3 accumulator piston and 2 springs.

NOTICE:


- Applying compressed air may cause the piston to jump out. When removing the piston, hold it using a waste cloth.
- Take care not to splash ATF when applying compressed air.

- (b) Remove the O-ring from the B-3 accumulator piston.




21. REMOVE MANUAL VALVE LEVER SHAFT RETAINER SPRING

- (a) Using needle-nose pliers, remove the manual valve lever shaft retainer spring.




22. REMOVE MANUAL DETENT SPRING SUB-ASSEMBLY

- (a) Remove the 2 bolts, manual detent spring and cover.




23. REMOVE PARKING LOCK PAWL BRACKET

- (a) Remove the 2 bolts and parking lock pawl bracket.

**24. REMOVE MANUAL VALVE LEVER SUB-ASSEMBLY**


- (a) Using a chisel and hammer, cut off and remove the spacer.




- (b) Using a pin punch ($\phi 35$ mm) and hammer, drive out the pin.

HINT:


Slowly drive out the pin so that it does not fall into the transaxle case.



- (c) Remove the manual valve lever shaft and manual valve lever.

**25. REMOVE PARKING LOCK ROD SUB-ASSEMBLY**

- (a) Remove the parking lock rod from the manual valve lever.

**26. REMOVE MANUAL VALVE LEVER SHAFT OIL SEAL**

- (a) Using a screwdriver, pry out the oil seal from the transaxle case.


NOTICE:

Do not apply excessive force when removing the oil seal.

27. FIX AUTOMATIC TRANSAXLE ASSEMBLY

- (a) Fix the transaxle case in place with the oil pump side facing up.

28. INSPECT INPUT SHAFT ENDPLAY (See page AX-212)




29. REMOVE TRANSAXLE HOUSING

- (a) Remove the 16 bolts.
- (b) Tap on the circumference of the transaxle housing with a plastic-faced hammer to remove the transaxle housing from the transaxle case.


NOTICE:

The differential may be accidentally removed when the transaxle housing is removed.




30. REMOVE OIL PUMP ASSEMBLY

- (a) Remove the 7 bolts and oil pump from the transaxle case.




31. REMOVE THRUST NEEDLE ROLLER BEARING

- (a) Remove the thrust needle roller bearing from the underdrive planetary gear.




32. REMOVE NO. 2 THRUST BEARING UNDERDRIVE RACE

- (a) Remove the thrust bearing race from the underdrive planetary gear.




33. REMOVE DIFFERENTIAL GEAR ASSEMBLY


- (a) Remove the differential gear from the transaxle case.

**34. REMOVE OVERDRIVE BRAKE GASKET**


- (a) Remove the 2 overdrive brake gaskets from the transaxle case.

**35. REMOVE FORWARD CLUTCH ASSEMBLY**


- (a) Remove the forward clutch from the transaxle case.




- (b) Remove the thrust needle roller bearing from the forward clutch.

**36. REMOVE MULTIPLE DISC CLUTCH HUB**


- (a) Remove the thrust needle roller bearing, multiple disc clutch hub, thrust needle roller bearing and No. 1 thrust bearing race from the transaxle case.

37. INSPECT MULTIPLE DISC CLUTCH HUB (See page [AX-209](#))**38. REMOVE UNDERDRIVE PLANETARY GEAR ASSEMBLY**

- (a) Remove the bolt and pawl shaft clamp.




(b) Remove the parking lock pawl shaft.



(c) Push the parking lock pawl.

HINT:


Failure to do so will cause interference when the underdrive planetary gear is removed.



(d) Remove the underdrive planetary gear from the transaxle case.


NOTICE:

Make sure that the underdrive planetary gear dose not fall out.




39. REMOVE PARKING LOCK PAWL

(a) Remove the spring, pawl pin and parking lock pawl.



40. REMOVE UNDERDRIVE CLUTCH ASSEMBLY


(a) Remove the underdrive clutch, thrust bearing and bearing race from the transaxle case.

**41. REMOVE UNDERDRIVE 1-WAY CLUTCH ASSEMBLY**


- (a) Using a screwdriver, remove the snap ring from the transaxle case.

NOTICE:


Do not apply excessive force when removing the snap ring.



- (b) Remove the underdrive 1-way clutch from the transaxle case.




- (c) Remove the outer race retainer from the 1-way clutch.

**42. REMOVE NO. 2 UNDERDRIVE CLUTCH DISC**

- (a) Using a screwdriver, remove the snap ring.


NOTICE:

Do not apply excessive force when removing the snap ring.




- (b) Remove the flange, 4 discs and 4 plates from the transaxle case.

43. INSPECT NO. 2 UNDERDRIVE CLUTCH DISC (See page [AX-209](#))




44. REMOVE TRANSAXLE REAR COVER SUB-ASSEMBLY

- (a) Remove the 11 bolts.
- (b) Tap on the circumference of the rear cover with a plastic hammer to remove the transaxle rear cover from the transaxle case.




45. REMOVE NO. 1 TRANSAXLE CASE PLUG

- (a) Remove the 4 plugs from the transaxle rear cover.
- (b) Remove the 4 O-rings from the 4 plugs.



46. REMOVE REAR CLUTCH OIL SEAL RING OUTER


- (a) Remove the 3 rear clutch oil seal rings from the transaxle rear cover.



47. REMOVE NEEDLE ROLLER BEARING


- (a) Using SST, remove the bearing from the transaxle rear cover.

SST 09387-00041 (09387-01021, 09387-01030, 09387-01040)



48. REMOVE NO. 1 GOVERNOR APPLY GASKET


- (a) Using a screwdriver, remove the 3 apply gaskets.

**49. REMOVE BRAKE APPLY TUBE**


- (a) Remove the bolt, clamp and brake apply tube.
- (b) Remove the clutch apply tube.
- (c) Remove the brake apply tube from the clamp.

NOTICE:


Do not bend the tubes.

**50. REMOVE DIRECT CLUTCH ASSEMBLY**


- (a) Remove the thrust bearing and the direct clutch from the transaxle case.

**51. REMOVE OVERDRIVE DIRECT CLUTCH HUB SUB-ASSEMBLY**


- (a) Remove the thrust bearing race, thrust bearing and overdrive direct clutch hub from the planetary gear.

52. INSPECT OVERDRIVE DIRECT CLUTCH DRUM SUB-ASSEMBLY (See page [AX-209](#))**53. REMOVE REAR PLANETARY SUN GEAR ASSEMBLY**


- (a) Remove the rear planetary sun gear from the transaxle case.



- (b) Remove the thrust needle roller bearing and thrust bearing race from the rear planetary sun gear.




- (c) Remove the planetary carrier thrust washer from the rear planetary sun gear.




54. REMOVE 1-WAY CLUTCH ASSEMBLY

- (a) Remove the 1-way clutch and thrust needle roller bearing from the transaxle case.




- (b) Remove the 1-way clutch inner race from the 1-way clutch.




55. REMOVE 1-WAY CLUTCH SLEEVE OUTER

- (a) Remove the 1-way clutch sleeve outer from the transaxle case.




56. REMOVE NO. 1 PLANETARY CARRIER THRUST WASHER

- (a) Remove the planetary carrier thrust washer from the planetary gear.


**57. REMOVE 2ND BRAKE CLUTCH DISC**

- (a) Using a screwdriver, remove the snap ring.
- (b) Remove the flange, 4 discs and 4 plates from the transaxle case.


58. INSPECT 2ND BRAKE CLUTCH DISC (See page [AX-210](#))**59. REMOVE 2ND BRAKE PISTON ASSEMBLY**

- (a) Using a screwdriver, remove the snap ring.


- (b) Remove the 2nd brake piston from the transaxle case.


**60. REMOVE REAR PLANETARY GEAR ASSEMBLY**

- (a) Using a screwdriver, remove the snap ring.




- (b) Remove the rear planetary gear from the transaxle case.





61. REMOVE INPUT SUN GEAR


- (a) Remove the 2 thrust needle roller bearings, thrust bearing race and input sun gear from the transaxle case.



62. REMOVE 1ST AND REVERSE BRAKE CLUTCH DISC

- (a) Remove the flange, 6 discs and 6 plates from the transaxle case.

63. INSPECT 1ST AND REVERSE BRAKE CLUTCH DISC (See page [AX-210](#))




64. REMOVE FRONT PLANETARY GEAR ASSEMBLY

- (a) Using a chisel and hammer, unstake the lock washer.


NOTICE:

Push down all the claws of the washer.


Otherwise SST cannot be fully pressed against the nut, and cannot loosen the nut.




- (b) Using SST, remove the nut.
SST 09387-00030, 09387-00080



- (c) Using SST and a press, press out the front planetary gear from the counter drive gear.
SST 09950-60010 (09951-00450), 09950-70010 (09951-07100)




- (d) Remove the front planetary gear from the brake hub.



65. REMOVE FRONT PLANETARY RING GEAR

- (a) Using a screwdriver, remove the snap ring and front planetary ring gear from the brake hub.



66. REMOVE 1ST AND REVERSE BRAKE RETURN SPRING SUB-ASSEMBLY

- (a) Place SST on the return spring, and compress the return spring with a press.

NOTICE:

Stop the press when the spring seat is lowered 1 to 2 mm (0.039 to 0.078 in.) from the snap ring groove to prevent the spring seat from being deformed.

SST 09387-00070

- (b) Using a snap ring expander, remove the snap ring.

NOTICE:

Do not expand the snap ring excessively.


67. INSPECT 1ST AND REVERSE BRAKE RETURN SPRING SUB-ASSEMBLY (See page AX-210)


68. REMOVE 1ST AND REVERSE BRAKE PISTON

- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the transaxle case to remove the 1st and reverse brake piston.


NOTICE:

- Applying compressed air may cause the piston to jump out. When removing the piston, hold it using a waste cloth.
- Take care not to splash ATF when applying compressed air.






- (b) Remove the 2 O-rings from the 1st and reverse brake piston.




69. REMOVE COUNTER DRIVE GEAR

- (a) Using SST and a press, remove the counter drive gear from the transaxle case.

SST 09950-60010 (09951-00590), 09950-70010 (09951-07100)




- (b) As shown in the illustration, tighten the 2 bolts evenly and make a clearance of approximately 20.0 mm (0.787 in.) between the counter drive gear and the inner race.




- (c) Using SST, remove the tapered roller bearing.

SST 09950-60010 (09951-00590), 09950-00020, 09950-00030, 09950-40011 (09957-04010)



70. REMOVE TRANSFER DRIVEN PINION FRONT BEARING


- (a) Using a snap ring expander, remove the snap ring.



- (b) Using SST and a press, remove the bearing outer race.

SST 09950-60020 (09951-00910)

71. REMOVE NO. 2 BREATHER PLUG



72. REMOVE UNDERDRIVE BRAKE RETURN SPRING SUB-ASSEMBLY

- (a) Place SST on the return spring, and compress the return spring with a press.

NOTICE:

Stop the press when the spring seat is lowered 1 to 2 mm (0.039 to 0.078 in.) from the snap ring groove to prevent the spring seat from being deformed.

SST 09387-00020

- (b) Using a snap ring expander, remove the snap ring.



NOTICE:

Do not expand the snap ring excessively.


73. INSPECT UNDERDRIVE BRAKE RETURN SPRING SUB-ASSEMBLY (See page [AX-210](#))

74. REMOVE UNDERDRIVE BRAKE PISTON

- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the transaxle case to remove the underdrive brake piston.




- (b) Remove the 2 O-rings from the underdrive brake piston.


**75. REMOVE NEEDLE ROLLER BEARING**

- (a) Using SST, remove the needle roller bearing from the transaxle case.


SST 09387-00041 (09387-01010, 09387-01030, 09387-01040)

**76. REMOVE UNDERDRIVE CLUTCH DRUM OIL SEAL RING**

- (a) Remove the 2 oil seal rings from the transaxle case.


**77. REMOVE NO. 1 TRANSAXLE CASE PLUG**

- (a) Remove the 2 transaxle case plugs.
(b) Remove the 2 O-rings from the 2 plugs.


**78. REMOVE UNDERDRIVE CYLINDRICAL ROLLER BEARING**

- (a) Using SST, remove the underdrive cylindrical roller bearing from the transaxle case.

SST 09514-35011

**79. REMOVE UNDERDRIVE OUTPUT SHAFT OIL SEAL RING**


- (a) Remove the oil seal ring from the transaxle housing.

**80. REMOVE DIFFERENTIAL GEAR LUBE APPLY TUBE**

- (a) Remove the bolt, transaxle apply tube clamp and differential gear lube apply tube from the transaxle housing.

NOTICE:

Do not bend the tubes.

**INSPECTION****1. INSPECT MULTIPLE DISC CLUTCH HUB**

- (a) Using a caliper gauge, measure the inside diameter of the forward clutch hub bushing.

Standard inside diameter:

23.03 to 23.05 mm (0.9067 to 0.9075 in.)


Maximum inside diameter:

23.09 mm (0.9091 in.)

NOTICE:

Check the contact surface of the bushing in the direct clutch shaft. If any scratch or discoloration is found, replace the direct clutch sub-assembly with a new one.

If the inside diameter is greater than the maximum, replace the forward clutch hub with a new one.


**2. INSPECT NO. 2 UNDERDRIVE CLUTCH DISC**

- (a) Check if the sliding surfaces of the disc, plate and flange are worn or burnt.

If necessary, replace them.

NOTICE:

- If the lining of the disc comes off or is discolored, or if a part of the groove is worn, replace all the discs.
- Before installing new discs, immerse them in ATF for at least 15 minutes.

**3. INSPECT OVERDRIVE DIRECT CLUTCH DRUM SUB-ASSEMBLY**

- (a) Using a caliper gauge, measure the inside diameter of the forward clutch hub bushing.

Standard inside diameter:

23.025 to 23.046 mm (0.9065 to 0.9073 in.)


Maximum inside diameter:

23.09 mm (0.9091 in.)

NOTICE:

Check the contact surface of the bushing in the direct clutch shaft. If any scratch or discoloration is found, replace the direct clutch sub-assembly with a new one.

If the inside diameter is greater than the maximum, replace the forward clutch hub with a new one.




4. INSPECT 2ND BRAKE CLUTCH DISC

- (a) Check if the sliding surface of the disc, plate and flange are worn or burnt.
If necessary, replace them.

NOTICE:

- If the lining of the disc comes off or is discolored, or if a part of the groove is worn, replace all the discs.
- Before installing new discs, immerse them in ATF for at least 15 minutes.




5. INSPECT 1ST AND REVERSE BRAKE CLUTCH DISC

- (a) Check if the sliding surface of the disc, plate and flange are worn or burnt.
If necessary, replace them.

NOTICE:

- If the lining of the disc comes off or is discolored, or if a part of the groove is worn, replace all the discs.
- Before installing new discs, immerse them in ATF for at least 15 minutes.




6. INSPECT 1ST AND REVERSE BRAKE RETURN SPRING SUB-ASSEMBLY

- (a) Using a vernier caliper, measure the free length of the spring together with the spring seat.

Standard free length:

17.61 mm (0.6933 in.)

If the result is not as specified, replace the spring.




7. INSPECT UNDERDRIVE BRAKE RETURN SPRING SUB-ASSEMBLY

- (a) Using a vernier caliper, measure the free length of the spring together with the spring seat.

Standard free length:

13.24 mm (0.5213 in.)

If the result is not as specified, replace the spring.



8. INSPECT PACK CLEARANCE OF 1ST AND REVERSE BRAKE

- (a) Using a vernier caliper, measure the distance between the disc surface and the contact surface of the 2nd brake cylinder and transaxle case (Dimension A).

- (b) Select an appropriate flange so that the pack clearance will meet the specified value.

Standard pack clearance:


1.16 to 1.35 mm (0.0457 to 0.0531 in.)

HINT:

Piston stroke = Dimension A - Flange thickness

Standard flange thickness

Mark	Thickness	Mark	Thickness
1	1.8 mm (0.071 in.)	5	2.2 mm (0.087 in.)
2	1.9 mm (0.075 in.)	6	2.3 mm (0.091 in.)
3	2.0 mm (0.079 in.)	7	2.4 mm (0.094 in.)
4	2.1 mm (0.083 in.)	8	2.5 mm (0.098 in.)

**9. INSPECT PACK CLEARANCE OF 2ND BRAKE**

- Using a vernier caliper, measure the distance between the disc surface and snap ring surface (Dimension B).
- Select an appropriate flange so that the pack clearance will meet the specified value.


Standard pack clearance:**0.62 to 0.91 mm (0.0244 to 0.0358 in.)**

HINT:

Piston stroke = Dimension B - Flange thickness - Snap ring thickness 1.6 mm (0.063 in.)

Standard flange thickness

Mark	Thickness	Mark	Thickness
1	3.0 mm (0.118 in.)	5	3.4 mm (0.134 in.)
2	3.1 mm (0.122 in.)	6	3.5 mm (0.138 in.)
3	3.2 mm (0.126 in.)	7	3.6 mm (0.142 in.)
4	3.3 mm (0.130 in.)	-	-

**10. INSPECT PACK CLEARANCE OF UNDERDRIVE BRAKE**

- Using a dial indicator, measure the underdrive brake pack clearance while applying and releasing compressed air (392 kPa, 4.0 kgf/cm², 57 psi).


Standard pack clearance:**1.81 to 2.20 mm (0.0713 to 0.0866 in.)**

HINT:


Select an appropriate flange from the table below so that it will meet the specified value.

Standard flange thickness

Mark	Thickness	Mark	Thickness
1	3.0 mm (0.118 in.)	4	3.1 mm (0.122 in.)
2	3.2 mm (0.126 in.)	5	3.3 mm (0.130 in.)
3	3.4 mm (0.134 in.)	-	-

**11. INSPECT UNDERDRIVE 1-WAY CLUTCH ASSEMBLY**

- Install the underdrive clutch assembly to the 1-way clutch.
- Check that the underdrive 1-way clutch locks when turned clockwise and rotates freely when turned counterclockwise as shown in the illustration. If the result is not as specified, replace the underdrive 1-way clutch.

**12. INSPECT INPUT SHAFT END PLAY**

- (a) Using a dial indicator, measure the input shaft end play.

Standard end play:

0.262 to 1.244 mm (0.0103 to 0.0490 in.)

If the result is not as specified, replace the input shaft or thrust needle roller bearing.