



SECOND BRAKE PISTON COMPONENTS

AX



● Non-reusable part

AX



DISASSEMBLY



1. REMOVE 2ND BRAKE PISTON RETURN SPRING SUB-ASSEMBLY

- (a) Place SST on the return spring and compress the return spring with a press.

SST 09387-00060

- (b) Using a screwdriver, remove the snap ring.

- (c) Remove the 2nd brake piston return spring.



2. REMOVE 2ND BRAKE PISTON



- (a) Hold the 2nd brake piston and apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the 2nd brake cylinder to remove the 2nd brake piston.

NOTICE:

Hold the piston with a shop rag or a piece of cloth when removing the piston. Failure to do so may result in the piston jumping out from the cylinder.

3. REMOVE 2ND BRAKE PISTON O-RING

- (a) Remove the 2 O-rings from the 2nd brake piston.



INSPECTION

1. INSPECT 2ND BRAKE PISTON RETURN SPRING SUB-ASSEMBLY

- (a) Using a vernier caliper, measure the free length of the spring together with the spring seat.

Standard free length:

16.61 mm (0.6539 in.)