


TOYOTA  
**CROWN**

电 路 图

GRS182 系列

2004年 11月



# CROWN

## 电路图

	章节代码	页码
导言 .....	A .....	2
如何使用本手册 .....	B .....	3
故障排除 .....	C .....	12
缩写词汇 .....	D .....	17
术语和符号表 .....	E .....	18
继电器位置分布图 .....	F .....	20
电路图 .....	G .....	62
系统电路 .....	H .....	90
接地点 .....	I .....	482
电源 ( 电流流程图 ) .....	J .....	490
连接器表 .....	K .....	502
连接器零件号 .....	L .....	518
总电路图 .....	M .....	524

## A 引言

本手册由以下 13 章组成:

号码	章节	简述
A	索引	本手册内容的索引。
	引言	每一章节的简要解释。
B	如何使用本手册	说明如何使用本手册。
C	故障排除	描述电路的基本检查步骤。
D	缩写词汇	定义本手册中使用的缩写词汇。
E	术语和符号表	定义主要零件的符号和功能。
F	继电器位置分布图	标示电子控制装置、继电器、继电器盒等的位置。 这一章与系统电路紧密相关。
G	电路图	描述零件连接器、接点、接地点等的位置。 这一章与系统电路紧密相关。
H	索引	系统电路的索引。
	系统电路	各系统电路图显示的是从电源开始到接地点的全部电路。根据连接方法通过代码来显示和分类电路连接和它们的位置(参见“如何使用本手册”一章)。本章中也包括用于故障排除的“系统概述”和“维修提示”。
I	接地点	显示本手册中所述的所有零件的接地位置。
J	电源(电流流程图)	描述从电源到各个电力负载的电源分配情况。
K	连接器表	描述本书中出现的零件的连接形状。 这一章与系统电路紧密相关。
L	连接器零件号	说明本手册中使用的连接器的零件号。
M	总电路图	提供表示电路连接的电路图。

## 如何使用本手册 B

本手册将车辆上安装的电路按所属系统划分, 提供关于它们的资料。


每个系统电路的实际配线是指从蓄电池开始的电源点出发直到每个接地点结束。(所有电路图显示的都是关闭所有开关时的状态。)

对任何故障进行故障排除时, 首先要了解发生故障的电路的工作原理(参见“系统电路”一章), 了解给此电路供电的电源的工作原理(参见“电源”一章), 和接地点的工作原理(参见“接地点”一章)。参见“系统概述”来了解电路工作原理。

了解电路原理后, 可以对故障电路进行故障排除, 找出故障原因。使用“继电器位置分布图”和“电路图”来找出每个零件、接线盒和线束连接器、线束和线束连接器、接点和每个系统电路的接地点。为了更好的了解接线盒内的连接情况, 也提供每个接线盒的内电路图。

在每个系统电路中用箭头(从 \_\_\_ 到 \_\_\_)表示与各个系统相关的配线。如果需要连接的情况, 参见本手册末尾的“总电路图”。

\*此系统图仅为参考样图，不同于“系统电路”一章中的实际电路。




[A] : 系统名称

[B] : 表示继电器盒。无阴影表示且只给出继电器盒号以区别接线盒  
例：①表示1号继电器盒

[C] : 当车辆型号、发动机类型或规格不同时，用( )表示不同的配线和连接器。

[D] : 表示相关系统。

[E] : 表示线束和线束连接器。带插头端子的线束用箭头(↗)表示。  
外侧数字为引脚号。




每个线束和线束连接器代码的第一个字母表示组件位置，如“发动机室”的“E”，仪表板和周围区域的“1”和车身及周围区域的“B”。

当两个以上的代码第1和第2个字母相同时，就增加数字(如IH1、IH2)，表示它们是相同类型的线束和线束连接器。

[F] : 表示零件(所有零件用天蓝色表示)。此代码与零件位置图中所用的代码相同。

[G] : 接线盒(圈内的数字是接线盒号，连接器代码在它旁边)。接线盒用阴影标出，以便将它与其它零件清楚地区别开来。

例：




[H] : 表示配线颜色。

配线颜色用字母表示。


B = 黑色 W = 白色 BR = 褐色  
L = 蓝色 V = 紫色 SB = 天蓝色  
R = 红色 G = 绿色 LG = 浅绿色  
P = 粉色 Y = 黄色 GR = 灰色  
O = 棕色  
第一个字母表示基本配线颜色，第二个字母表示条纹的颜色。

例： L - Y



[I] : 表示配线接点(发动机室的代码为“E”、仪表板的代码为“1”、车身的代码为“B”)。

例：



接点 IS 的位置是阴影部分表示。

[J] : 表示屏蔽电缆。




[K] : 表示连接器引脚的编号。

这个编号系统对于插头和插座连接器是不同的。

例：从左上到右下依次标出编号

从右上到左下依次标出编号



[L] : 表示接地点。

每个接地点的代码的第一个字母表示组件位置，如“发动机室”的“E”，仪表板和周围区域的“1”和车身及周围区域的“B”。

[M] : 页码

## B 如何使用本手册

[N]

### 系统概述

始终将电流通过制动灯保险丝加到制动灯开关的端子 2 上。打开点火开关，电流从仪表保险丝流到灯光故障传感器的端子 4，同时也经过后灯警告灯流到灯光故障传感器的端子 4。

**制动灯断开警告**  
制动灯断开警告(制动灯开关 ON)，如果制动灯电路开路，且从灯光故障传感器的端子 7 流到端子 1、2 的电流改变，则灯光故障传感器检测到这个断开，并且灯光故障传感器的警告电路被激活。因此，电流从灯光故障传感器的端子 4 流到端子 11，再流到接地，并点亮后灯警告灯。通过踩下制动踏板，流到灯光传感器的端子 8 的电流保持警告电路 ON，并在关闭点火开关之前一直点亮警告灯。

[O] **维修提示**

### S6 制动灯开关

2-1: 踩下制动踏板时关闭

### L4 灯光故障传感器

1、2、7-接地: 制动灯开关打开时大约 12 V

4、8-接地: 点火开关 ON 时大约 12 V

11-接地: 始终导通

[P] **零件位置**

代码	参见页	代码	参见页	代码	参见页
C7	34	L4	36	R7	37
H17	36	R6	37	S6	35

[Q] **继电器盒**

代码	参见页	继电器盒 (继电器盒位置)
I	18	1 号继电器盒 (左仪表盘支架)

[R] **接线盒和线束连接器**

代码	参见页	接线盒和线束 (连接器位置)
IB	20	仪表盘配线和仪表盘接线盒 (下饰板)
3C	22	仪表盘配线和 3 号接线盒 (左仪表盘支架)

[S] **连接线束的连接器 and 线束**

代码	参见页	连接线束和线束 (连接器位置)
IE1	42	地板配线和仪表盘配线 (左脚踏板)
BV1	50	行李箱配线和地板配线 (左行李箱)

[T] **接地点**

代码	参见页	接地点位置
BL	50	左侧中立柱下方
BO	50	中间后端板

[U] **接点**

代码	参见页	带接点的线束	代码	参见页	带接点的线束
I5	44	前围板配线	B18	50	行李箱配线

B


[N]: 解释系统概述。

[O]: 显示参考值或解释故障排除中要参考的功能。

[P]: 显示系统电路中的零件在车辆上的位置的参考页码。

例: 零件“L4”(灯光故障传感器)在手册的 36 页。

\* 代码中的字母是零件的第一个字母，数字表示此零件在以此字母开始的零件中的序列中的位置。



[Q]: 显示系统电路中的继电器盒连接器在车辆上的位置的参考页码。

例: 在本手册的 18 页中描述了连接器“1”，它被安装在仪表板的左侧。

[R]: 显示系统电路中的接线盒和线束在车辆上的位置的参考页码。

例: 连接器“3C”连接仪表盘配线和 3 号接线盒。在本手册的 22 页中描述了此连接器，它被安装在仪表板的左侧。

[S]: 显示描述线束和线束连接器 (首先显示插座线束，然后显示接头线束) 的参考页码。

例: 连接器“IE1”连接地板配线 (插座) 和仪表盘配线 (插头)。在本手册的 42 页中描述了此连接器，它被安装在左侧脚踏板上。

[T]: 显示车辆上接地点位置的参考页码。

例: 在本手册的 50 页描述了接地点“BO”，它安装在中间后端板上。



[U]: 显示车辆上接点位置的参考页码。

例: 接点“I5”位于前围板线束上，在本手册的 44 页给予说明。



## B 如何使用本手册


## K 连接器表



[B]



J 2



[C]



[D]




[A] : 表示连接到零件的连接器。(数字表示引脚号)

[B] : 连接接头

表示连接到短路端子的连接器。

连接接头



本手册中的连接接头包括连接到许多线束的短路端子。必须在短路端子安装时进行检查。

[C] : 零件代码

代码的第一个字母是零件的第一个字母，数字表示此零件在以相同字母开始的零件序列中的位置。

[D] : 连接器颜色

凡没有标明的连接器都是乳白色。

## L 连接器零件号

代码	零件名	零件号	代码	零件名	零件号
A 1	空调环境温度传感器	90980-11070	D 4	一根管 (白灯)	90980-11608
A 2	空调冷凝器风扇电机	90980-11237	D 5	一根管 (车内灯)	90980-10982
A 3	空调冷凝器风扇继电器	90980-10940	D 6	一根管 (月亮天窗)	90980-11608
A 4	空调冷凝器风扇继电器	90980-10928	D 7	白锁控制继电器	90980-10848
A 5	空调电脑离合器	90980-11271	D 8	左侧门锁控制开关	90980-11148
A 6	自动变速器油温传感器	90980-11413	D 9	右侧门锁控制开关	90980-11097
[A]	ABS 执行器	908 [C] 151	D 10	左侧门控灯开关	
A 8	ABS 执行器	90980-11009	D 11	右侧门控灯开关	90980-11097
A 9	左前 ABS 速度传感器	90980-10941	D 12	左前门白控灯开关	
A 10	右前 ABS 速度传感器	90980-11002	D 13	右前门白控灯开关	90980-11156
A 11	左前空气囊传感器	90980-11856	D 14	左后门白控灯开关	
A 12	右前空气囊传感器		D 15	右后门白控灯开关	
A 13		90980-11194	D 16		90980-11170

[A] : 零件代码


[B] : 零件名

[C] : 零件号

显示丰田零件号。

不能完全提供上述所有的连接器零件号。

## C 故障排除



### 电压检查

(a) 在如下情况下检查点存在电压。



例:

- [A] - 点火开关 ON
- [B] - 点火开关和 SW 1 打开
- [C] - 点火开关、SW 1 和继电器打开 (SW 2 关闭)

(b) 用电压表将负极导线连接到好的接地点或蓄电池负极端子上, 正极导线连接到连接器或组件端子上。  
用测试灯代替电压表也能进行电压检查。


### 导通性和电阻检查

- (a) 断开蓄电池端子或配线, 从而使检查点间没有电压。
- (b) 用欧姆表的两根导线接触检查点两端。



如果电路有二极管, 则反接两根导线, 再次进行检查。  
将负极导线接二极管正极侧, 正极导线接触负极侧, 应显示导通。  
如果将两根导线反接, 则应显示不导通。

- (c) 用高阻抗 (最小 10 kΩ/V) 电压表 / 欧姆表对电路进行故障排除。



### 查找短路电路

- (a) 拆下熔断的保险丝并断开保险丝的所有载荷。
- (b) 在保险丝的位置连接测试灯。
- (c) 在如下情况下测试灯亮。


例:

- [A] - 点火开关 ON
- [B] - 点火开关和 SW 1 打开
- [C] - 点火开关、SW 1 和继电器开 (连接继电器) 和 SW 2 关闭 (或断开 SW 2)

- (d) 查看测试灯时, 断开和重新连接连接器。  
短路位于测试灯仍点亮的连接器和测试灯熄灭的连接器之间。
- (e) 沿车身轻轻晃动故障配线以准确找出短路位置。


注意:

- (a) 除非绝对有必要不要打开盖或 ECU 的壳。(如果接触 IC 端子, 静电可能会损坏 IC。)
- (b) 更换数字仪表的内部机构 (ECU 部分) 时, 小心身体或衣物的任一部分不要与更换零件 (备用零件) IC 等的导线的端子接触。








### 插头和插座连接器的断开

为了扯开连接器, 只是拉连接器自身, 而不是线束。  
提示: 扯开之前, 先要检查要断开的是哪类连接器。





## C 故障排除



### 如何更换端子 (带端子挡块或次级锁止设备)

1. 准备专用工具

提示: 为了从连接器上拆下端子, 请建构和使用专用工具或左图所示的类似物体。

2. 断开连接器

3. 分开次级锁止设备或端子挡块。

(a) 释放端子锁止夹或从连接器上拆下端子前, 必须先分开锁止设备。

(b) 使用专用工具或端子起子开锁次级锁止设备或端子挡块。

小心:

不要从连接器体上拆下端子挡块。

[A] 非防水型连接器





提示: 探针插入位置根据连接器形状(端子数等等)而改变, 所以, 插入之前, 先检查插入位置。

“范例 1”

将端子挡块升高到暂时锁止位置。

“范例 2”

打开次级锁止设备。



[B] 防水型连接器

提示: 端子挡块颜色根据连接器颜色不同而不同。

例:

端子挡块: 连接器体  
黑色或白色: 灰色  
黑色或白色: 深灰色  
灰色或白色: 黑色

“范例 1”

端子挡块被拔起到暂时锁止位置的类型(拔起型)。


将专用工具插入端子挡块检修孔(▲ 标记)并将端子挡块拉起暂时锁止位置。

提示: 探针插入位置根据连接器形状(端子数等等)而改变, 所以, 插入之前, 先检查插入位置。


“范例 2”

如图所示, 直接将工具插入端子挡块的检修孔内。

## C 故障排除



将端子挡块向下推到暂时锁止位置。




(c) 从端子上释放锁块，并从后部拉出端子。

4. 将端子安装到连接器上。

(a) 插入端子。


提示：

1. 确保端子被正确定位。
2. 插入端子直到锁块紧固锁止。
3. 将带端子挡块的端子插入到暂时锁止位置。



(b) 将次级锁止设备或端子挡块推入完全锁止位置。

5. 连接连接器






















## 缩写词汇

本手册中使用的缩写词汇如下。

A/C	=	空调
A/T	=	自动变速器
ABS	=	防抱死制动系统
ACIS	=	声控进气系统
AVC-LAN	=	视频音频通信 - 局域网
BA	=	制动辅助
BEAN	=	车身电子局域网
CAN	=	控制器局域网
DLC3	=	数据链路连接器 3
ECT	=	电子控制变速器
ECU	=	电子控制装置
EPS	=	电机动力转向
ESA	=	电子点火提前
ETCS-i	=	智能电子节气门控制系统
EVAP	=	燃油蒸汽排放
IC	=	集成电路
J/B	=	接线盒
LH	=	左侧
R/B	=	继电器盒
RH	=	右侧
SFI	=	连续多点燃油喷射
SRS	=	乘员保护辅助系统
SW	=	开关
TEMP.	=	温度
TRC	=	牵引控制
VSC	=	车辆稳定控制
VSV	=	真空控制阀
VVT-i	=	智能可变气门正时
w/	=	带
w/o	=	不带


\* 组件中给出的名称是端子名称 (端子代码)，但不能被认为是缩写词汇。

	<b>蓄电池</b> 存储化学能并将之转化为电能。给汽车的各个电路提供直流电。		<b>接地</b> 指配线连接车身的点，从而给电路提供一个回路。如果没有接地，则电流不能流动。
	<b>电容器 (电容器)</b> 小型临时电压保持装置。		<b>前照灯</b> 电流导致前照灯灯丝加热并发光。前照灯即可以有一根(1)灯丝也可以有两根(2)灯丝。
	<b>点烟器</b> 电阻加热元件。		<b>喇叭</b> 发出高频音频信号的设备。
	<b>断路器</b> 断路器是一根可重新使用的保险丝，如果流经的电流过强，断路器将变热并断开。冷却之后一些装置自动重新设定，而另一些必须手动重新设定。		<b>点火线圈</b> 将低压直流电转换为点燃火花塞的高压点火电流。
	<b>二极管</b> 仅允许电流单向流通的半导体。		<b>灯</b> 流经灯丝的电流加热灯丝并使之发光。
	<b>二极管, 稳压二极管</b> 此二极管仅到规定电压时允许电流单向流通并阻碍逆向流动。超过该电压, 则由其分流降压。它可以简单地起调压器的作用。		<b>LED (发光二极管)</b> 基于电流, 这些二极管不同于一般的灯, 它发光但不产生热量。
	<b>光敏二极管</b> 光敏二极管是根据光线的多少控制电流的半导体。		<b>模拟型仪表</b> 电流将起一个电磁线圈, 这将会导致探针的移动。从而, 提供一个相对于背景刻度的相关显示。
	<b>分电器, IIA</b> 将高压电流从点火线圈引导到每个火花塞。		<b>数字型仪表</b> 电流启动 LED、LCD 或荧光显示器中的一个或数个, 将提供一个相关或数字的显示。
	<b>保险丝</b> 这是一薄的金属片, 如果太多的电流经过, 就会熔断, 从而切断电流来保护电路免受损坏。 (中等电流保险丝)		<b>电机</b> 这是将电能转换为机械能的电源装置, 特别是对于旋转运动。
	<b>保险熔丝</b> 这是位于强电流电路中的粗导线, 如果电流超载将会熔断, 从而保护电路。数字表示导线的横截面积。 (强电流保险丝或保险熔丝)		


	<b>1. 正常关闭</b>	<b>继电器</b> 基本上, 这是可以正常关闭(1)或打开(2)的电子操作开关。流经小线圈的电流将产生电磁场, 会打开或关闭附近的开关。		<b>扬声器</b> 这是可以根据电流产生声音的机电设备。
	<b>2. 正常打开</b>			<b>手动开关</b> 打开或关闭电路, 从而停止(1)或流通(2)电流。
	<b>双投继电器</b> 这是电流流经一组接点或其它组的继电器。			<b>1. 正常打开</b> <b>2. 正常关闭</b>
	<b>电阻器</b> 这是具有固定电阻的电子元件, 安装在电路中用来将电压降低到规定值。			<b>双投开关</b> 这是电流持续流经一组接点或其它组的开关。
	<b>抽头电阻器</b> 这是有两个或多个不同不可调电阻值的电阻器。			<b>点火开关</b> 这是键操作开关, 它有几个位置允许各个电路变为可操作的, 特别是初级点火电路。
	<b>滑动电阻器或可变电阻器</b> 这是可调电阻比的可控电阻器。有时也将之称为电位计或变阻器。			<b>刮水器停止开关</b> 关闭刮水器开关时, 此开关自动经刮水器返回到停止位置。
	<b>传感器 (热敏电阻)</b> 这个电阻器可以根据温度而改变它的电阻。			<b>晶体管</b> 这是典型的被用作电子继电器的固体电路设备; 根据“基数”提供的电压切断或流通电流。
	<b>速度传感器</b> 此传感器使用电磁脉冲来打开和关闭产生启动其它部件的信号。的信号。的开关。 (舌簧开关型)			<b>配线</b> (1) 没有连接
	<b>短路销</b> 用于在接线盒中提供不可断的连接。			(2) 接合
	<b>电磁销</b> 这是电磁线圈, 当电流流经时, 会形成一个磁场来移动活塞等等。			在电路图中, 配线通常用直线表示。在汇合处没有黑色圆点的交叉配线(1)没有接合。在汇合处有黑色圆点或八角形(○)标记的交叉配线(2)接合。

## F 继电器位置分布图


【发动机室】




【仪表板】



【车身】




【座椅】





# F 继电器位置分布图



[1号发动机室继电器盒和1号发动机室接线盒内电路]



## F 继电器位置分布图



- ① : 2号发动机室继电器盒
- ② : 2号发动机室接线盒

左发动机室 (参见 20 页)



# F 继电器位置分布图

[2号发动机室继电器盒和2号发动机室接线盒内电路]









# F 继电器位置分布图

左前围板侧板 (参见 20 页)


○ : 驾驶员侧接线盒




视图 A




视图 B




视图 C



F 继电器位置分布图  
[驾驶员侧接线盒内电路]



(接下页)



(接上页)


驾驶员侧接线盒 ECU

(接下页)


# F 继电器位置分布图

右前围板侧板 (参见 20 页)


○ : 前乘员侧接线盒




视图 A




视图 B



视图 C




【前乘员侧接线盒内电路】



(接下一页)


(接上页)




# F 继电器位置分布图

仪表板加强件右侧 (参见 20 页)

○ : 右中间接线盒








(接下页)


(接上页)




# F 继电器位置分布图


仪表板加强件右侧 (参见 20 页)

○ : 左中间接线盒






(接下页)




F 继电器位置分布图

行李箱左侧 (参见 21 页)


○ : 行李箱接线盒




视图 A




视图 B



视图 C



F 继电器位置分布图  
 [行李箱接线盒内电路]




# F 继电器位置分布图

左脚踏板 (参见 20 页)


连接线接头

(1 号 CAN)



[ 连接线接头 (1 号 CAN) 内电路 ]

J10 (A), J11 (B), J12 (C), J13 (D), J14 (E), J15 (F), J31 (G)  
连接线接头








## G 电路图

### 发动机室内零件的位置




- A 1 空调压缩机
- A 2 空调压力传感器
- A 3 空气流量计
- A 4 空燃比传感器(1排, 传感器1)
- A 5 空燃比传感器(2排, 传感器1)
- A 6 空燃比传感器(左前)
- A 7 空气囊传感器(右前)
- A 8 交流发电机
- A 9 交流发电机
- A10 环境温度传感器

- B 1 蓄电池电流传感器
- B 2 蓄电池温度传感器
- B 3 制动液液面警告开关

- C 1 凸轮轴正时机油控制阀(左侧排气)
- C 2 凸轮轴正时机油控制阀(左侧进气)
- C 3 凸轮轴正时机油控制阀(右侧排气)
- C 4 凸轮轴正时机油控制阀(右侧进气)
- C 5 示宽灯(左前)
- C 6 示宽灯(右前)
- C 7 冷却风扇 ECU
- C 8 曲轴位置传感器
- C 9 2号曲轴位置传感器(左侧排气)
- C10 2号曲轴位置传感器(右侧排气)
- C11 2号曲轴位置传感器(右侧进气)
- C12 3号曲轴位置传感器(左侧进气)

### 发动机室内零件的位置




- E 1 ECT 电磁阀
- E 2 发动机 ECU
- E 3 发动机 ECU
- E 4 发动机 ECU
- E 5 发动机 ECU
- E 6 发动机 ECU
- E 7 发动机 ECU
- E 8 发动机罩灯控开关
- E 9 机油油位传感器
- E10 机油压力开关

- F 1 雾灯(左前)
- F 2 雾灯(右前)
- F 3 喷油嘴(1号)
- F 4 喷油嘴(2号)
- F 5 喷油嘴(3号)
- F 6 喷油嘴(4号)
- F 7 喷油嘴(5号)
- F 8 喷油嘴(6号)
- F 9 燃油泵电阻器
- F30 前刮水器除冰器

- H 1 前照灯(左远光)
- H 2 前照灯(左近光)
- H 3 前照灯(右远光)
- H 4 前照灯(右近光)
- H 5 前照灯清洁剂控制继电器
- H 6 前照灯清洁剂电机
- H 7 前照灯方向控制电机(左)
- H 8 前照灯方向控制电机(右)
- H 9 喇叭(高音)
- H10 喇叭(低音)




仪表板内零件的位置




- |                          |               |
|--------------------------|---------------|
| A11 空调放大器 (前)            | B 4 鼓风机电机 (前) |
| A12 空调放大器 (前)            | B 5 制动踏板路感开关  |
| A13 空调室内温度传感器            |               |
| A14 自动变速器换挡杆照明           | C13 点烟器       |
| A15 加速踏板位置传感器            | C14 时钟        |
| A17 中央安全气囊传感器总成          | C15 组合仪表      |
| A18 中央安全气囊传感器总成          | C16 组合开关      |
| A19 中央安全气囊传感器总成          | C17 组合开关      |
| A20 安全气囊引爆管 (驾驶员侧膝盖安全气囊) |               |
| A21 安全气囊引爆管 (前乘客侧安全气囊总成) |               |
| A22 安全气囊引爆管 (前乘客侧安全气囊总成) |               |
| A23 安全气囊引爆管 (前乘客侧膝盖安全气囊) |               |
| A24 安全气囊引爆管 (方向盘衬垫)      |               |
| A25 天线放大器                |               |
| A26 自动灯控传感器              |               |
| A33 空调放大器 (前)            |               |

仪表板内零件的位置



- |                    |                         |
|--------------------|-------------------------|
| D 1 二极管            | G 1 网关 ECU              |
| D 2 DLC3           | G 2 手套箱灯                |
| D 3 驾驶员侧接线盒 ECU    |                         |
| D 4 驾驶员侧接线盒 ECU    | H11 前照灯清洁剂开关            |
| D 5 驾驶员侧接线盒 ECU    | H12 前照灯方向控制 ECU         |
| D 6 驾驶员侧接线盒 ECU    | H13 加热型氧传感器 (1排, 传感器 2) |
|                    | H14 加热型氧传感器 (2排, 传感器 2) |
| E11 ECT 模式选择开关     | I 7 点火开关                |
| E17 电子钥匙振荡器 (后控制台) | I 8 仪表板调节器总成            |
|                    | I 9 集成控制面板总成            |
| F10 足部照明灯 (左前)     | I10 离子发生器               |
| F11 足部照明灯 (右前)     |                         |
| F12 前乘客侧接线盒 ECU    |                         |
| F13 前乘客侧接线盒 ECU    |                         |
| F14 前乘客侧接线盒 ECU    |                         |
| F15 前乘客侧接线盒 ECU    |                         |
| F16 加油口盖开启器开关      |                         |
| F31 前刮水器除冰器开关      |                         |

仪表盘内零件的位置



- J 8 连接线接头  
J 9 连接线接头  
J10 连接线接头  
J11 连接线接头  
J12 连接线接头  
J13 连接线接头  
J14 连接线接头  
J15 连接线接头  
J16 连接线接头  
J17 连接线接头  
J18 连接线接头  
J31 连接线接头  
J32 连接线接头  
J33 连接线接头

- K 3 钥匙取消开关  
K 4 钥匙孔  
K 5 钥匙孔

- L 1 灯控可变电阻器  
L 2 行李舱门开启器取消开关


- M 4 复式显示器  
M 5 复式显示器  
M 6 复式显示器  
M 7 复式显示器  
M 8 复式显示器  
M 9 复式显示器  
M10 复式显示器

- O 1 外后视镜开关

- P 6 驻车制动开关  
P 7 电源插座 (前)  
P 32 电源控制 ECU  
P 33 电源开关

- R 1 收音机总成  
R 2 收音机总成  
R 3 收音机总成  
R 4 后电动座椅开关 (回位控制)  
R 5 后遮阳帘开关  
R 6 后视镜收缩器开关  
R 28 收音机总成

仪表盘内零件的位置



- S 8 座椅加热器开关 (左前)  
S 9 座椅加热器开关 (右前)  
S10 换档锁止控制 ECU  
S11 扬声器 (中间)  
S12 螺旋电缆  
S13 转向传感器  
S14 制动灯开关  
S34 转向锁止 ECU


- T 8 倾斜和伸缩 ECU  
T 9 倾斜电机  
T10 轮胎压力警告开关  
T11 牵引控制开关  
T12 变速器控制开关  
T13 收发器钥匙放大器  
T14 收发器钥匙 ECU  
T15 计程器开关  
T16 转向信号闪光灯  
T17 高音喇叭 (左前)  
T18 高音喇叭 (右前)  
T19 电视摄像头控制器  
T20 电视摄像头控制器

- U 1 未锁警告开关

- V 3 VSC 警告蜂鸣器

- Y 1 偏移率传感器


车体内零件的位置



- A27 空调放大器(后)  
 A29 空气囊传感器(左后)  
 A30 空气囊传感器(右后)  
 A31 烟灰缸照明(左后)  
 A32 烟灰缸照明(右后)  
 B 6 鼓风机电机(后)  
 B 7 鼓风机电阻器(后)  
 C18 中央制动灯  
 C19 中央制动灯  
 C20 门控灯(左前门)  
 C21 门控灯(右前门)  
 C22 门控灯(左后门)  
 C23 门控灯(右后门)  
 C24 帘式空气囊引爆管(左)  
 C25 帘式空气囊引爆管(右)

- D 7 阻尼器伺服电机(后空气混合)  
 D 8 门控接收器  
 D 9 门控灯开关(驾驶员侧)  
 D10 门控灯开关(前乘员侧)  
 D11 门控灯开关(左后)  
 D12 门控灯开关(右后)  
 D13 门锁总成(驾驶员侧)  
 D14 门锁总成(前乘员侧)  
 D15 门锁总成(行李箱)  
 D16 门锁总成(左后)  
 D17 门锁总成(右后)  
 D18 驾驶员门 ECU  
 D19 驾驶员门 ECU  
 D20 驾驶员门 ECU  
 D21 车门外侧把手(左前)  
 D22 车门外侧把手(右前)  
 D23 车门外侧把手(左后)  
 D24 车门外侧把手(右后)

车体内零件的位置



- E12 电子钥匙天线(行李箱)  
 E13 电子钥匙振荡器(左前门)  
 E14 电子钥匙振荡器(右前门)  
 E15 电子钥匙振荡器(行李箱内侧)  
 E16 电子钥匙振荡器(行李箱外侧)  
 E18 电子钥匙振荡器(左后门)  
 E19 电子钥匙振荡器(右后门)  
 E20 电子钥匙振荡器(后座椅)  
 F17 前乘员门 ECU  
 F18 前乘员门 ECU  
 F19 前乘员门 ECU  
 F20 前座椅内安全带(驾驶员侧)  
 F21 前座椅外安全带(左)  
 F22 前座椅外安全带(左)  
 F23 前座椅外安全带(右)  
 F24 前座椅外安全带(右)  
 F25 加油口盖开启器电机  
 F26 燃油量传感器  
 F27 吸油泵和计量表总成

- J21 连接线接头  
 J22 连接线接头  
 J23 连接线接头  
 J24 连接线接头  
 J25 连接线接头  
 J26 连接线接头  
 L 3 牌照灯(左)  
 L 4 牌照灯(右)  
 L 5 行李箱门锁芯  
 L 6 行李箱门锁  
 L 7 行李箱门开启器开关(左前门)  
 M 1 电磁阀(后)  
 M 2 地图灯(左)  
 M 3 地图灯(右)  
 N 2 静噪滤波器(中央制动灯)  
 O 3 顶置接线盒


H15 高度控制传感器



## G 电路图

### 座椅内零件的位置

【前座椅】



F28 前座椅内安全带 (驾驶员侧)  
 F29 前座椅内安全带 (前乘客侧)  
 F32 足部照明灯 (左后)  
 F33 足部照明灯 (右后)

J27 连接线接头  
 J28 连接线接头  
 J29 连接线接头  
 J30 连接线接头


P18 位置控制 ECU 和开关  
 P19 位置控制 ECU 和开关  
 P20 电动座椅电机 (驾驶员座椅前垂直控制)  
 P21 电动座椅电机 (驾驶员座椅后垂直控制)  
 P22 电动座椅电机 (驾驶员座椅滑动控制)  
 P23 电动座椅电机 (驾驶员座椅倾斜控制)  
 P24 电动座椅电机 (前乘客座椅倾斜控制)  
 P25 电动座椅电机 (前乘客座椅滑动控制)  
 P26 电动座椅电机 (腰部支撑)  
 P27 电动座椅开关 (驾驶员座椅)  
 P28 电动座椅开关 (前乘客座椅)  
 P29 电动座椅开关 (前乘客座椅)  
 P30 电动座椅开关 (腰部支撑)

S31 座椅加热器 (左前)  
 S32 座椅加热器 (右前)

G

### 座椅内零件的位置

【后座椅】



P31 电源插座 (后)


R26 后控制器  
 R27 后控制器

S33 座椅加热器 (后)


## G 电路图

□ : 连接线束的连接器和线束位置分布图


▽ : 接地点的位置分布图



○ : 接点位置分布图



## 连接线束的连接器和线束




代码	连接线束和线束(连接器位置分布图)
EA1	2号发动机配线和发动机室主配线(2号发动机室继电器盒内侧)
EA2	
EA3	
EB1	发动机室主配线和发动机配线(ECU盒内侧)
EC1	制动防滑控制传感器配线和发动机室主配线(右发动机室)
ED1	制动防滑控制传感器配线和发动机室主配线(左发动机室)
EE1	发动机配线和7号发动机配线(进气歧管后)
EF1	6号发动机配线和发动机配线(进气歧管后)
EG1	发动机配线和5号发动机配线(3号发动机室继电器盒附近)




## G 电路图


□: 连接线束的连接器和线束位置分布图



▽: 接地点位置分布图




连接线束的连接器和线束




代码	连接线束和线束 (连接器位置分布图)
IA1	仪表板配线和车顶配线 (仪表板左侧)
IA2	仪表板配线和车顶配线 (仪表板左侧)
IB1	发动机室主配线和 2 号地板配线 (左前围板侧板)
IB2	发动机室主配线和 2 号地板配线 (左前围板侧板)
IC1	左前门配线和 2 号地板配线 (左踏脚板)
IC2	左前门配线和 2 号地板配线 (左踏脚板)
ID1	仪表板配线和发动机室主配线 (左踏脚板)
ID2	仪表板配线和发动机室主配线 (左踏脚板)
IE1	仪表板配线和 2 号地板配线 (左踏脚板)

## G 电路图


□: 连接线束的连接器和线束位置分布图



○: 接点位置分布图




## 连接线束的连接器和线束




代码	连接线束和线束 (连接器位置分布图)
IF1	仪表板配线和仪表板配线总成 (仪表板加强件右侧)
IG1	仪表板配线和2号仪表板配线 (仪表板中间)
IH1	右前门配线和地板配线 (右脚踏板)
IH2	仪表板配线和发动机室主配线 (右脚踏板)
I1	发动机室主配线和地板配线 (右脚踏板)
IK1	仪表板配线和地板配线 (后控制台下)
IL1	仪表板配线和地板配线 (右脚踏板)
IM1	仪表板配线和2号地板配线 (后控制台下)

## G 电路图


□: 连接线束的连接器和线束位置分布图



▽: 接地点位置分布图




## 连接线束的连接器和线束




代码	连接线束和线束 (连接器位置分布图)
BA1	左前门配线和2号左前门配线 (左前门内侧)
BB1	右前门配线和2号右前门配线 (右前门内侧)
BC1	2号后门配线和左后门配线 (左后门内侧)
BD1	2号后门配线和2号地板配线 (左中立柱)
BE1	1号后门配线和地板配线 (右中立柱)
BF1	1号后门配线和右后门配线 (右后门内侧)

## G 电路图


□ : 连接线束的连接器和线束位置分布图




○ : 接点位置分布图



连接线束的连接器和线束



代码	连接线束和线束(连接器位置分布图)
BG1	左后制动防滑控制传感器配线和2号地板配线(左后车轮罩)
BH1	制动防滑控制传感器配线和地板配线(右后车轮罩)
B11	2号地板配线和后空调分配线(左后地板隔板)
BJ1	地板配线和2号地板配线(右后地板隔板)
BM1	左前门配线和左前电子钥匙配线(左前门内侧)
BN1	右前门配线和右前电子钥匙配线(右前门内侧)
BO1	左后电子钥匙配线和2号后门配线(左后门内侧)
BP1	右后电子钥匙配线和1号后门配线(右后门内侧)




配线名称	端子	颜色	规格
地板配线			
左前座椅配线			
右前座椅配线			


## G 电路图

□: 连接线束的连接器和线束位置分布图


【后座椅】



○: 接点位置分布图



### 连接线束的连接器和线束



代码 连接线束和线束(连接器位置分布图)

BK1 2号右后座椅配线和2号地板配线(左后座椅背面)

BL1 2号右后座椅配线和1号左后座椅配线(右后座椅背面)



## CROWN

### 电路图

### 系统电路

	页码
车内灯	192
充电	191
导航系统	440
倒车灯	233
灯自动关闭系统	233
点火	114
点烟器	399
电动窗	306
电动前盖和伸座	422
电动座椅 (不带驾驶员位置存储器的驾驶员座椅)	408
电动座椅 (带驾驶员位置存储器的驾驶员座椅)	402
电动座椅 (后乘员座椅)	412
电动座椅 (前乘员座椅)	416
电源	92
电源插座	400
电子张力调节器	414
多路通信系统 (AVC-LAN)	158
多路通信系统 (BEAN)	162
多路通信系统 (CAN)	154
ECT 和 A/T 指示器	142
EPS	356
发动机控制	116
发动机停机系统 (不带智能进入和启动系统)	138
防盗	284
丰田驻车辅助 (倒车导向监视器)	440
蜂窝式移动电话	440
后窗除雾器	399
后视镜加热器	418
后雾灯	188
后遮阳帘	421
滑动天窗	376
换挡锁止	438
加油口盖开启器	416
空调 (后)	478
空调 (前)	466
喇叭	394
冷却风扇	464
轮胎压力警告系统	332
门锁控制	242
启动 (不带智能进入和启动系统)	108
前窗除冰器	388
前刮水器和洗涤剂	382
前雾灯	174
前照灯	168
前照灯方向控制	356
前照灯清洁剂	360
SRS	341



	页码
时钟	396
TRC	332
VSC	208
尾灯	270
无线门锁控制 (不带智能进入和启动系统)	376
行李厢门开启器	320
巡航控制	364
遥控后视镜	450
音响系统	302
钥匙提醒器	214
照明	228
制动灯	100
智能进入和启动系统	100
* 按钮启动	100
* 发动机停机	254
* 无线门锁	100
* 转向锁止	186
转向信号和应急警告灯	234
自动灯控	456
组合仪表	288
座椅安全带警告	436
座椅加热器 (后)	434
座椅加热器 (前)	434



\* 1: w/ Smart Entry & Start System  
 \* 2: w/o Smart Entry & Start System







## 電源

### Service Hints

#### P32 Power Source Control ECU (w/ Smart Entry & Start System)

- 12-33-Ground : Always approx. 12 volts  
 11-Ground : Approx. 12 volts with the power SW at IG ON or ACC ON position  
 34, 35-Ground : Approx. 12 volts with the power SW at IG ON position  
 6-Ground : Always continuity

#### I7 Ignition SW (w/ Smart Entry & Start System)

- 2-3 : Closed with the ignition key at ON or ACC position  
 2-4 : Closed with the ignition key at ON or ST position  
 7-6 : Closed with the ignition key at ON or ST position  
 7-8 : Closed with the ignition key at ST position

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
E2	63	J5	A 64	J25	B 71
I7	67	J6	B 64	P32	68
J4	64	J24	A 71	P33	68

### ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No.2 (Engine Compartment Left)

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A		
1B		
1C		
1D		
1E	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
1F		
1G		
1H		
1I		
1J		
2A		
2C	27	Engine Room Main Wire and Engine Room J/B No.2 (Engine Compartment Left)
2D		
2E		
4A	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
5K	45	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
DD	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DJ	34	Floor No.2 Wire and Driver Side J/B (Cowl Side Left)
DM	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
DN		
LB		
LC	55	Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
LF		
PA		
PD	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PK		
PM	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)
PN		

### □ : Connector Joining Wire Harness and Wire Harness



Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	78	Engine Room Main Wire and Floor No.2 Wire (Left Cowl Side Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)

### ▽ : Ground Points

Code	See Page	Ground Points Location
EF	76	Rear Side of the Front Left Fender Apron
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH
BQ	82	Rear Floor Partition Panel LH



按按钮启动, 发动机停机和转向锁止





## 按按钮起动机, 发动机停机和转向锁止

### System Outline

#### Smart Ignition Function

- When the power SW is pushed with brake pedal depressed, ID code is confirmed in the vehicle. When it is confirmed, the engine immobilizer allows the engine to start.
- When the power SW is pushed without brake pedal depressed, ID code is confirmed in the vehicle. When it is confirmed, the engine immobilizer allows the power supply mode to change "ACC ON" to "IG ON" to "OFF" in circles by pushing the power SW.
- If the power SW is pushed under vehicle's stationary condition with the engine running, the engine stops and engine immobilizer is set.

### Service Hints

#### P32 Power Source Control ECU

- 33, 12-Ground: Always approx. 12 volts
- 34, 35-Ground: Approx. 12 volts with the power SW at IG ON position
- 11-Ground: Approx. 12 volts with the power SW at IG ON or ACC ON position
- 6-Ground: Always continuity
- 1-Ground: Approx. 12 volts with the brake pedal depressed

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	J5, A	64	R11	72
A18	66	J6, B	64	R14	72
C15	66	J8, A	68	S2	65
D19	70	J9, B	68	S6, A	65
E2, A	63	K4, A	68	S7, B	65
E3, B	63	K5, B	68	S10	69
E5, D	63	N1	64	S14	69
F17	71	P10	72	S34	69
G1	67	P32	68	T14	69
J4	64	P33	68		

### ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No. 1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No. 2 (Engine Compartment Left)

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	23	Engine Room Main Wire and Engine Room J/B No. 1 (Near the Front Right Suspension Tower)
1G		
4A		
4B		
4C	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4D		
4E		
4K		
5A	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5C		
5D		
5E		
5F		
5G		
5K	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DA		
DD	34	Floor No. 2 Wire and Driver Side J/B (Cowl Side Left)
DJ		
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
PA		
PD	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PK		
PL	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)
PM		


### □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
IC2	78	Front Door LH Wire and Floor No. 2 Wire (Left Kick Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IH2	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
IJ2	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BA1	82	Front Door LH Wire and Front Door LH No. 2 Wire (Inside of the Front Door LH)
BD1	82	Rear Door No. 2 Wire and Floor No. 2 Wire (Left Center Pillar)
BE1	82	Rear Door No. 1 Wire and Floor Wire (Right Center Pillar)
BJ1	84	Floor Wire and Floor No. 2 Wire (Rear Floor Partition Panel RH)

### ▽ : Ground Points

Code	See Page	Ground Points Location
EC	76	Rear Side of the Front Right Fender Apron
EF	76	Rear Side of the Front Left Fender Apron
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH

# 起动 (不带智能进入和起动系统)



## Service Hints

### N1 Neutral Start SW

9-6 : Closed with the shift lever in P or N position

### S6 (A), S7 (B) Starter

Point closed with the neutral start SW at P or N position and the Ignition SW at ST position

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
D1	67	J3	64	N1	64
E2	A 53	J4	64	S6	A 65
E5	D 63	J5	A 64	S7	B 65
I7	67	J6	B 64		

### □ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No.2 (Engine Compartment Left)

### □ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
TB		
ID		
1E	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
1G		
5D		
5L	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
PD	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PM		
PN	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)

### □ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)

### ▽ : Ground Points


Code	See Page	Ground Points Location
EC	76	Rear Side of the Front Right Fender Apron




From Power Source System (See Page 92)



E 81AL E 30BL E 61E  
Engine ECU





From Power Source System (See Page 92)

**Service Hints**  
**A8 (A), A9 (B) Alternator**  
 (B) 1-Ground - Always approx. 12 volts  
 (A) 2-Ground - Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

**Parts Location**

Code	See Page	Code	See Page	Code	See Page
A8	A 62	E2	A 63	J9	B 68
A9	B 62	E3	B 63	J10	A 58, 68
A11	66	E6	E 83	J15	F 58, 68
A18	66	G1	67	J16	A 60, 68
B1	62	J5	A 54	J31	G 58, 68
B2	62	J6	B 54	J32	D 60, 68
C15	66	J8	A 68	J33	E 60, 68

**Relay Blocks**

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)

**Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
1L	23	Engine Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
4D		
4E	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4K		
SD	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5G		
DA	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD		
DK	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		
PK	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)

**Connector Joining Wire Harness and Wire Harness**



Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)

**Ground Points**

Code	See Page	Ground Points Location
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH

**Splice Points**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E15	76	Engine Room Main Wire			



## Service Hints

11, 12, 13, 14, 15, 16 Ignition Coil (No.1, No.2, No.3, No.4, No.5, No.6)  
 1-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position  
 (Power SW type)  
 4-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
E4	C 63	M	64	J3	64
E8	E 63	15	64	N3	64
		16	64	N4	64
J1	64				
J2	64	J1	A 64		
J3	64	J2	B 64		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	26	Engine Room R/B No.2 (Engine Compartment Left)

## □ : Connector Joining Wire Harness and Wire Harness



Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)

## ▽ : Ground Points


Code	See Page	Ground Points Location
EH	76	Right Side of Cylinder Head
EI	76	Left Side of Cylinder Head

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	76	Engine Wire	E10	76	Engine Wire
E7					




# 发动机控制







From Power Source System (See Page 52)

- \* 1. w/ Smart Entry & Start System
- \* 2. w/ Smart Entry & Start System











# 发动机控制







## 发动机控制

### System Outline

This system utilizes an engine ECU and maintains overall control of the engine, transmission and so on. An outline of the engine control is explained here.

#### 1. Input Signals

- (1) Water temp. signal circuit  
The water temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the engine coolant temp. The engine coolant temp. is input into TERMINAL THW of the engine ECU as a control signal.
- (2) Intake air temp. signal circuit  
The intake air temp. sensor is installed in the air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine ECU.
- (3) Oxygen sensor signal circuit  
The oxygen density in the exhaust emission is detected and is input as a control signal from the heated oxygen sensors (Bank 1 sensor 2 and bank 2 sensor 2) to TERMINALS OX1B and OX2B of the engine ECU.  
To stabilize detection performance by the heated oxygen sensors, the heated oxygen sensors are warmed. This heater is also controlled by the engine ECU (HT1B and HT2B).
- (4) RPM signal circuit  
Crankshaft position is detected by the crankshaft position sensor No.2 (RH exhaust side, RH intake side and LH exhaust side), crankshaft position sensor No.3 (LH intake side) and their signals are input to TERMINALS EV1+, EV2+, VV1+ and VV2+ of the engine ECU as control signals. Also, the engine RPM is detected by the crankshaft position sensor installed in the cylinder block and the signal is input into TERMINAL NE+ of the engine ECU as a control signal.
- (5) Throttle signal circuit  
The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINALS VTA1 and VTA2 of the engine ECU.
- (6) Air fuel ratio signal circuit  
The air fuel ratio is detected and input as a control signal into TERMINALS A1A+ and A2A+ of the engine ECU.
- (7) Accelerator signal circuit  
The Accelerator position sensor detects the accelerator pedal opening degree. And the control signal is input in the TERMINALS VPA and VPA2 of the engine ECU.
- (8) Battery signal circuit  
Voltage is constantly applied to the battery terminal of the engine control module. When the ignition SW is turned to ON, voltage for engine ECU operation is applied via the EFI MAIN relay to TERMINALS +B and +B1 of the engine ECU.
- (9) Intake air volume signal circuit  
Intake air volume is detected by the air flow meter and the signal is input to TERMINAL VG of the engine ECU as a control signal.
- (10) Stop lamp SW signal circuit  
The stop lamp SW is used to detect whether or not the vehicle is braking and the signal is input into TERMINAL STP of the engine ECU as a control signal.
- (11) Starter signal circuit  
To confirm whether the engine is cranking, the voltage applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine ECU as a control signal.
- (12) Engine knock signal circuit  
Engine knocking is detected by knock control sensors (Bank 1 and bank 2) and the signal is input into TERMINALS KMK1 and KMK2 as a control signal.
- (13) VVT-i signal circuit  
The camshaft timing oil control valves (LH exhaust side, LH intake side, RH exhaust side and RH intake side) detects the real valve timing. And the control signal is input in TERMINALS OE1+, OE2+, OC1+ and OC2+ of the engine ECU.

#### 2. Control System

##### SFI system

The SFI system monitors the engine condition through the signals, which are input from each sensor to engine ECU. The best fuel injection volume is decided based on this data and the program memorized by the engine ECU, and the control signal is output to TERMINALS #10, #20, #30, #40, #50 and #60 of the engine ECU to operate the injector (inject conditions).

##### ESA system

The ESA system monitors the engine condition through the signals, which are input to the engine ECU from each sensor. The best ignition timing is decided according to this data and the memorized data in the engine ECU, and the provide the best ignition timing for the driving conditions.

##### Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emissions is low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine ECU evaluates the signals from each sensor, current is output to TERMINALS HT1B and HT2B, controlling the heater.

##### Air fuel ratio sensor heater control system

The air fuel ratio sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emission is low), and warms up the air fuel ratio sensor to improve detection performance of the sensor. The engine ECU evaluates the signals from each sensor, current is output to TERMINALS HAT1A and HAT2A, controlling the heater.

##### ACIS

ACIS includes a valve in the bulkhead separating the surge tank into two parts. This valve is opened and closed in accordance with the driving conditions to control the intake manifold length in two stages for increased engine output in all ranges from low to high speeds.

The engine ECU judges the engine speed by the signals from each sensor and outputs signals to the TERMINAL ACIS to control the VSV (ACIS).

##### ETCS-I

The ETCS-I controls the engine output at its optimal level corresponding to the opening of the throttle valve under all driving conditions.

##### Fuel pump control

The engine ECU outputs current to TERMINAL FPR and controls the F/PMP relay and fuel pump drive speed in response to driving conditions.

#### 3. Diagnosis System

When a malfunction is observed in the engine ECU signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can be found by reading the code displayed by the check engine indicator lamp.

#### 4. Fail-Safe System

When a malfunction has occurred in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine ECU memory or else stops the engine.

## 发动机控制

### Service Hints

#### W1 Water Temp. Sensor

- 1-2 : Approx. 15.04 kΩ (20°C, -4°F)
- Approx. 5.74 kΩ (0°C, 32°F)
- Approx. 2.45 kΩ (20°C, 68°F)
- Approx. 1.15 kΩ (40°C, 104°F)
- Approx. 0.584 kΩ (60°C, 140°F)
- Approx. 0.318 kΩ (80°C, 176°F)

#### E2 (A), E3 (B), E4 (C), E5 (D), E6 (E), E7 (F) Engine ECU

- BATT- : Always 9.0-14.0 volts
- +B-E1 : 9.0-14.0 volts (Ignition SW at ON position (Ignition SW type) or power SW at IG ON position (Power SW type))
- VC-E1 : 4.5-5.5 volts (Ignition SW at ON position (Ignition SW type) or power SW at IG ON position (Power SW type))
- VTA1-E3 : 0.5-1.1 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and throttle valve fully closed)
- : 3.2-4.8 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and throttle valve fully open)
- VTA2-E3 : 2.1-3.1 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and throttle valve fully closed)
- : 4.5-5.5 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and throttle valve fully open)
- VG-E2G : 0.5-3.0 volts (Engine idling)
- THA-E3 : 0.5-3.4 volts (Engine idling and intake air temp. 20°C, 68°F)
- THW-E2 : 0.2-1.0 volts (Engine idling and engine coolant temp. 80°C, 176°F)
- IGF1-E1 : Pulse generation (Engine idling)
- IGF2-E1 : Pulse generation (Engine idling)
- VV1+ ~VV1- : Pulse generation (Engine idling)
- VV2+ ~VV2- : Pulse generation (Engine idling)
- NE+ ~NE- : Pulse generation (Engine idling)
- STA-E1 : 6.0 volts or more (Engine cranking)
- FC-E1 : 9.0-14.0 volts (Ignition SW at ON position (Ignition SW type) or power SW at IG ON position (Power SW type))
- : 0-3.0 volts (Engine idling)
- PRG-E01 : 9.0-14.0 volts (Ignition SW at ON position (Ignition SW type) or power SW at IG ON position (Power SW type))
- : Pulse generation (Engine idling)
- TACH-E1 : Pulse generation (Engine idling)
- STP-E1 : 7.5-14.0 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and brake pedal depressed)
- : 0-1.5 volts (Ignition SW on (Ignition SW type) or power SW IG on (Power SW type) and brake pedal released)
- KNK1, KNK2-E1 : Pulse generation (Engine idling)
- HT1B, HT2B-E1 : 9.0-14.0 volts (Ignition SW at ON position (Ignition SW type) or power SW at IG ON position (Power SW type))
- : 0-3.0 volts (Engine idling)
- IGT1, IGT2, IGT3, IGT4, IGT5, IGT6-E1 : Pulse generation (Engine idling)
- #10, #20, #30, #40, #50, #60-E01 : Pulse generation (Engine idling)

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	62	E6	E 63	J6	B 64
A4	62	E7	F 63	J8	A 68
A5	62	E9	63	J9	B 68
A8	62	E10	63	J10	A 58, 68
A10	62	F3	63	J12	C 58, 68
A11	66	F4	63	J13	D 58, 68
A15	66	F5	63	J15	E 58, 68
A18	66	F6	63	J16	A 60, 68
B1	62	F7	63	J31	G 58, 68
B2	62	F8	63	J32	D 60, 68
C1	62	F9	63	J33	E 60, 68
C2	62	F17	71	K1	64
C3	62	F27	71	K2	64
C4	62	G1	67	N1	64
C7	62	H13	67	P10	72
C8	62	H14	67	P32	68
C9	62	I1	64	P33	68
C10	62	I2	64	R11	72
C11	62	I3	64	R14	72
C12	62	I4	64	S2	65
C15	66	I5	64	S14	69
D1	67	J6	64	T1	65
D2	67	J7	67	T14	A 69
D19	70	J1	A 64		B 69
E2	A 63	J2	B 64	V1	65
E3	B 63	J3	64	Y2	65
E4	C 63	J4	64	W1	65
E5	D 63	J5	A 64		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No 1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No 2 (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
1D		
1E		
1G		
1I		
2A	27	Engine Room Main Wire and Engine Room J/B No.2 (Engine Compartment Left)
2B		
2C		
4A	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4D		
4E		
4K		
4L		
5A	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5C		
5D		
5E		
5G		
6A	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
6D		
7J	34	Floor No.2 Wire and Driver Side J/B (Cowl Side Left)
7L	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
8A	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
8K		
9I	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)
9Y		

○ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
1	76	Engine Room No.2 Wire and Engine Room Main Wire (Inside of the Engine Room R/B No.2)
2		
1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
1	76	Engine Wire and Engine No.7 Wire (Behind the Intake Manifold)
1	76	Engine No.6 Wire and Engine Wire (Behind the Intake Manifold)
1	76	Engine Wire and Engine No.5 Wire (Near the Engine Room R/B No.3)
1	78	Engine Room Main Wire and Floor No.2 Wire (Left Cowl Side Panel)
2	78	Front Door LH Wire and Floor No.2 Wire (Left Kick Panel)
2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
2	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
1	82	Front Door LH Wire and Front Door LH No.2 Wire (Inside of the Front Door LH)
1	82	Rear Door No.2 Wire and Floor No.2 Wire (Let Center Pillar)
1	82	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)



▽ : Ground Points

Code	See Page	Ground Points Location
EC	76	Rear Side of the Front Right Fender Apron
EE	76	Rear Side of the Front Left Fender Apron
EH	76	Right Side of Cylinder Head
EI	76	Left Side of Cylinder Head
IK	76	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH
BG	82	Rear Floor Partition Panel LH

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	76	Engine Wire	E9	76	Engine Wire
E4			E14	76	Engine Room Main Wire
E7			E15		
E8	76	Engine No.5 Wire			

# 发动机机系统 (不带智能进入和起动系统)



# 发动机停机系统 (不带智能进入和起动系统)

## Service Hints

### T14 Transponder Key ECU

- 1-Ground : Always approx. 12 volts
- 2-Ground : Approx. 12 volts with the ignition SW at ON position
- 16-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C15	66	F12	A 67	P10	72
C16	66	F14	C 67	R11	72
D3	A 67	F15	D 67	R14	72
D5	C 67	F17	71	T13	69
D9	70	G1	67	T14	69
D19	70	J24	A 71	T15	69
E3	63	J25	B 71	U1	69

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	27	Engine Room Main Wire and Engine Room J/B No 2 (Engine Compartment Left)
4B	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4C		
4D		
4E		
4K		
5A	45	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5C		
5D		
5G	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD		
DJ		
LC		
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		

## □ : Connector Joining Wire Harness and Wire Harness



Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	78	Front Door LH Wire and Floor No 2 Wire (Left Kick Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IE1	78	Instrument Panel Wire and Floor No 2 Wire (Left Kick Panel)
IH2	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BA1	82	Front Door LH Wire and Front Door LH No 2 Wire (Inside of the Front Door LH)
BD1	82	Rear Door No 2 Wire and Floor No 2 Wire (Left Center Pillar)
BE1	82	Rear Door No 1 Wire and Floor Wire (Right Center Pillar)
BU1	84	Floor Wire and Floor No 2 Wire (Rear Floor Partition Panel RH)

## ▽ : Ground Points

Code	See Page	Ground Points Location
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IR	78	Cowl Side Panel RH



# ECT 和 A/T 指示器





- \* 1: w/ Smart Entry & Start System
- \* 2: w/o Smart Entry & Start System

# ECT 和 A/T 指示器

From Power Source System (See Page 92)

- 1. w/ Smart Entry & Start System
- 2. w/o Smart Entry & Start System







E 1 ECT Subroad

E 2 ECT ECU

# ECT and A/T 指示器

From Power Source System (See Page 82)





## System Outline

Previous automatic transmissions have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the line pressure, throttle pressure, lock-up pressure and accumulator pressure etc. through the solenoid valve. The electronically controlled transmission is a system which precisely controls gear shift timing and lock-up timing in response to the vehicle's driving conditions and the engine condition detected by various sensors. It makes smooth driving possible by shift selection for each gear which is the most appropriate to the driving conditions at that time, and by preventing downshifting and gear shift shock when starting off.

## 1. Gear Shift Operation

When driving, the engine warm up condition is input as a signal to TERMINAL THW of the engine ECU from the water temp. sensor and the vehicle speed signal from vehicle speed sensor is input to TERMINAL SPD of the engine ECU. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINALS VTA1 and VTA2 of the engine ECU as throttle angle signal. Based on these signals, the engine ECU selects the best shift position for the driving conditions and sends current to the ECT solenoid.

## 2. Line Hydraulic Pressure Control

The engine ECU adjusts the line hydraulic pressure to the optimal level by controlling TERMINAL SLT+ of the engine ECU according to the engine torque data. This realizes the smooth gear shifting.

## 3. Lock-Up and Flexible Lock-Up Control

The engine ECU carries out the lock-up control by controlling the TERMINAL SLU+ of the engine ECU according to the shift position, vehicle speed, throttle opening degree and running conditions. The engine ECU also steadily keeps applying the lock-up clutch a delicate slippage to improve the transmission efficiency (Fuel efficiency) of the torque converter.

## 4. Stop Lamp SW Circuit

If the brake pedal is depressed (Stop lamp SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine ECU. The engine ECU operates and cuts the current to the solenoid to release lock-up.

## 5. AI-Shift Control

The engine ECU judges whether the road is downslope or upslope by detecting the throttle opening degree or the vehicle's speed. Moreover it can expect the winding roads by detecting the turning condition of the vehicle. The engine ECU keeps unnecessary shifting up from the fourth gear from operating and carries out the automatic shifting down to the third gear in order to control the vehicle running according to the road conditions. The engine ECU also reads the driver's intention during driving from his (her) accelerating operation and the running conditions of the vehicle. As a result of that, ideal shifting pattern for each driver are automatically selected without any switching operations.

## 6. Sequential Shift Operation

With the sequential shift function, the manual shift lever becomes available by setting the shift lever to the S position, and the S and shift range position indicators appear in the combination meter. Any desired range can be selected by shifting up or down the shift lever.

## Service Hints

## E2 (A), E4 (C), E5 (D), E6 (E), E7 (F) Engine ECU

(A) 4, (C) 5—Ground : Always approx. 12 volts

(A) 17—Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

(A) 2, (C) 4, (C) 6, (D) 7, (E) 1, (E) 2, (F) 3, (F) 5—Ground : Always continuity

## N1 Neutral Start SW

3-1 : Closed with the shift lever in P position

3-2 : Closed with the shift lever in R position

3-5 : Closed with the shift lever in N position

3-7 : Closed with the shift lever in D position

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	F11	71		
A15	66	G1	67	J32	D 60, 68
A18	66	I7	67	J33	E 60, 68
C15	66	J1	A 64	N1	64
C16	66	J2	B 64	P10	72
D1	67	J3	64	P32	68
D2	67	J4	64	P33	68
D3	A 67	J5	A 64	R11	72
D5	C 67	J6	B 64	R14	72
D19	70	J8	A 68	S2	65
E1	63	J9	B 68	S14	69
E2	A 63	J10	A 58, 68	T1	65
E3	B 63	J12	C 58, 68	T2	65
E4	C 63	J13	D 58, 68	T3	65
E5	D 63	J15	E 58, 68	T12	69
E6	E 63	J16	A 60, 68	T14	A 69
E7	F 63	J24	A 71		B 69
E11	67	J25	B 71	W1	65
F14	C 67	J31	G 58, 68		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No.2 (Engine Compartment Left)

## ECT 和 A/T 指示器

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	23	Engine Room Main Wire and Engine Room J/B No. 1 (Near the Front Right Suspension Tower)
1E		
1G		
2A	27	Engine Room Main Wire and Engine Room J/B No. 2 (Engine Compartment Left)
2F		
4A		
4C	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4D		
4E		
4F		
4G		
4K		
4L		
5A	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5C		
5D		
5E		
5G		
5K		
5L		
DA	33	Instrument Panel Wire and Driver Side J/B (Cow Side Left)
DD		Floor No. 2 Wire and Driver Side J/B (Cow Side Left)
DJ	34	
DK	34	Engine Room Main Wire and Driver Side J/B (Cow Side Left)
DL		Floor No. 2 Wire and Luggage Room J/B (Luggage Room Left)
LC	55	
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cow Side Right)
PD		
PK		
PL	40	Engine Room Main Wire and Front Passenger's Side J/B (Cow Side Right)
PN		

### □ : Connector Joining Wire Harness and Wire Harness



Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
IC2	78	Front Door LH Wire and Floor No. 2 Wire (Left Kick Panel)
IO2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IH2	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
II2	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BA1	82	Front Door LH Wire and Front Door LH No. 2 Wire (Inside of the Front Door LH)
BD1	82	Rear Door No. 2 Wire and Floor No. 2 Wire (Left Center Pillar)
BE1	82	Rear Door No. 1 Wire and Floor Wire (Right Center Pillar)
BJ1	84	Floor Wire and Floor No. 2 Wire (Rear Floor Partition Panel RH)

### ▽ : Ground Points

Code	See Page	Ground Points Location
EC	76	Rear Side of the Front Right Fender Apron
EE	76	Rear Side of the Front Left Fender Apron
EH	76	Right Side of Cylinder Head
EI	76	Left Side of Cylinder Head
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH

# 多路通信系统 (CAN)

From Power Source System (See Page 93)



## 多路通信系统 (CAN)

### System Outline

CAN has two lines as a pair which make communication with operating voltage. CAN has excellent data speed and error detecting capacity. It consists of vehicle control systems such as engine ECU, yiw rate sensor, power steering ECU, skid control ECU with actuator, steering sensor, DLC3, television camera controller (w/ navigation system) and gateway ECU. Gateway ECU has communication circuit to correspond with different types of communication data. Different types of communication data can be shared among communication parts after it goes through gateway ECU.

This system is working for the following systems:

- + ABS
- + Air Conditioner (Front)
- + Back-Up Light
- + Cellular Mobile Telephone
- + Combination Meter
- + Cruise Control
- + ECT and A/T Indicator
- + Engine Control
- + EPS
- + Front Wiper and Washer
- + Navigation System
- + Rear Sunshade
- + Rear Window Defogger
- + Remote Control Mirror
- + SRS
- + Starting
- + TOYOTA Parking Assist (Back Guide Monitor)
- + TRC
- + VSC

### Service Hints

#### G1 Gateway ECU

2-Ground : Approx. 12 volts with the ignition SW at ON or ACC position (Ignition SW type) or with the power SW at IG ON or ACC ON position (Power SW type)

1-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

10-Ground : Always approx. 12 volts

24-Ground : Always continuity

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
D2	67	J13	D 58, 68	J33	E 60, 68
E2	63	J14	E 58, 68	P1	64
G1	67	J15	F 58, 68	S2	65
J8	A 68	J16	A 60, 68	S13	69
J9	B 68	J17	B 60, 68	T19	69
J10	A 58, 68	J18	C 60, 68	Y1	69
J11	B 58, 68	J31	G 58, 68		
J12	C 58, 68	J32	D 60, 68		

### ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	Z2	Engine Room R/B No. 1 (Near the Front Right Suspension Tower)

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
4C	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4E		
4F		
4I		
4K		
5A	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5D		
5G		
5I		
DA	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		

### □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
I12	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)

### ▽ : Ground Points

Code	See Page	Ground Points Location
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH






# 多路通信系统 (AVC-LAN)



▽ : Ground Points

Code	See Page	Ground Points Location
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH



# 多路通信系统 (BEAN)

From Power Source System (See Page 82)



## 多路通信系统 (BEAN)

### System Outline

BEAN consists of body electrical systems such as transponder key ECU, sliding roof control ECU, front passenger's door ECU, rear door LH ECU, rear door RH ECU, driver door ECU, power window master SW, A/C amplifier (Front), rear controller, A/C amplifier (Rear), airbag sensor assembly center, combination meter, luggage room J/B ECU, front passenger's side J/B ECU, front controller, combination SW, driver side J/B ECU, tilt and telescopic ECU, gateway ECU, power source control ECU (w/ smart entry system), smart key ECU (w/ smart entry & start system) and position control ECU. Gateway ECU has communication circuit to correspond with different types of communication data. Different types of communication data can be shared among communication parts after it goes through gateway ECU. Vehicle information is input to driver side J/B ECU at an assembling plant as a representative ECU which delivers the information to other ECUs through multiplex communication.

This system is working for the following systems:

- \* ABS
- \* Air Conditioner (Front)
- \* Air Conditioner (Rear)
- \* Audio System
- \* Automatic Light Control
- \* Back-Up Light
- \* Combination Meter
- \* Cruise Control
- \* Door Lock Control
- \* ECT and A/T Indicator
- \* Engine Control
- \* Engine Immobilizer System (w/ Smart Entry & Start System)
- \* Engine Immobilizer System (w/o Smart Entry & Start System)
- \* EPS
- \* Front Fog Light
- \* Front Wiper and Washer
- \* Headlight
- \* Headlight Beam Level Control
- \* Headlight Cleaner
- \* Horn
- \* Illumination
- \* Interior Light
- \* Key Reminder
- \* Light Auto Turn Off System
- \* Luggage Compartment Door Opener
- \* Mirror Heater
- \* Power Seat (Driver's Seat w/ Driving Position Memory)
- \* Power Tilt and Power Telescopic
- \* Power Window
- \* Push Button Start System
- \* Rear Fog Light
- \* Rear Sunshade
- \* Rear Window Defogger
- \* Remote Control Mirror
- \* Seat Belt Warning
- \* Sliding Roof
- \* SPS
- \* Starting
- \* Steering Lock (w/ Smart Entry & Start System)
- \* Stop Light
- \* Taillight
- \* Tire Pressure Warning System
- \* Theft Deterrent
- \* Turn Signal and Hazard Warning Light
- \* TRC
- \* VSC
- \* Wireless Door Lock Control (w/ Smart Entry & Start System)
- \* Wireless Door Lock Control (w/o Smart Entry & Start System)

### Service Hints

#### G1 Gateway ECU

- 2-Ground : Approx. 12 volts with the ignition SW at ON or ACC position (ignition SW type) or with the power SW at IG ON or ACC ON position (Power SW type)
- 1-Ground : Approx. 12 volts with the ignition SW at ON position (ignition SW type) or with the power SW at IG ON position (Power SW type)
- 10-Ground : Always approx. 12 volts
- 24-Ground : Always continuity

#### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	F17	71		
A18	66	G1	67	P32	68
A27	70	J8	A 68	R11	72
C15	66	J9	B 68	R14	72
C16	66	J24	A 71	R26	75
D2	67	J25	B 71	S20	73
D3	A 67	J27	A 74	S36	73
D5	C 67	J28	B 74	T8	69
D19	70	P10	72	T14	A 69
F14	C 67	P19	74		B 69

#### ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No. 1 (Near the Front Right Suspension Tower)

#### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	27	Engine Room Main Wire and Engine Room J/B No. 2 (Engine Compartment Left)
4C		
4E		
4F	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4I		
4K		
5A		
5B		
5C		
5D	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5E		
5G		
5I		
DA		
DD	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DJ	34	Floor No. 2 Wire and Driver Side J/B (Cowl Side Left)
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
LC	55	Floor No. 2 Wire and Luggage Room J/B (Luggage Room Left)
PA		
PD	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)


## 多路通信系统 (BEAN)

### □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	78	Instrument Panel Wire and Roof Wire (Left Side of the Instrument Panel)
IC2	78	Front Door LH Wire and Floor No.2 Wire (Left Kick Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IH2	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IA1	82	Front Door LH Wire and Front Door LH No.2 Wire (Inside of the Front Door LH)
BA1	82	Front Door LH Wire and Floor No.2 Wire (Left Center Pillar)
BD1	82	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BE1	82	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BE1	82	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BI1	84	Floor No.2 Wire and Rear A/C Sub Wire (Rear Floor Partition Panel LH)
BI1	84	Floor No.2 Wire and Rear A/C Sub Wire (Rear Floor Partition Panel LH)
BJ1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)
BJ1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)
BK1	88	Rear Seat RH No.2 Wire and Floor No.2 Wire (Back the Rear Seat LH)

### ▽ : Ground Points


Code	See Page	Ground Points Location
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH




# 前照灯

CTE  
Continuation Mark


From Power Source System (See Page 82)




From Power Source System (See Page 82)




From Power Source System (See Page 92)



CHIAL C1710E  
Combination SW



From Power Source System (See Page 92)



## Service Hints

**Front Controller**  
6-Ground : Approx. 12 volts with the Ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)  
22, 23-Ground : Always approx. 12 volts  
11-Ground : Always continuity

**C16 (A) Combination SW**  
(A) 2-Ground : Approx. 12 volts with the Ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)  
(A) 1-Ground : Always approx. 12 volts  
(A) 5-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	F12	A 67	J6	64
A18	66	F14	C 67	J8	A 68
C15	66	G1	67	J9	B 68
C16	A 66	H1	63	J24	A 71
C17	B 66	H2	63	J25	B 71
D3	A 67	H3	63		
D5	C 67	H4	63		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)
2	26	Engine Room R/B No.2 (Engine Compartment Left)

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
2E		
2F	27	Engine Room Main Wire and Engine Room J/B No.2 (Engine Compartment Left)
2G		
2C		
40		
44		Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4K		
5A		
5D		
5G	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5I		
5J		
DA		
DD	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
LC	55	Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
PA		
PD	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PK		
PL	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA2	76	Engine Room No.2 Wire and Engine Room Main Wire (Rear Side of the Engine Room R/B No.2)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
II2	60	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BJ1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)

## ▽ : Ground Points

Code	See Page	Ground Points Location
EA	76	Front Side of Front Right Fender Apron
ED	76	Front Side of Front Left Fender Apron
EE	76	Rear Side of the Front Left Fender Apron
EE	78	Cowl Side Panel LH
IK	78	Left Side of Shift Lever
IL	78	Cowl Side Panel RH
IN	78	Cowl Side Panel RH

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	76	Engine Room No.2 Wire			







## ▽ : Ground Points


Code	See Page	Ground Points Location
ED	76	Front Side of Front Light Fender Apron
EE	76	Rear Side of the Front Left Fender Apron
IK	76	Cowl Side Panel LH
IL	76	Left Side of Shift Lever
IN	76	Cowl Side Panel RH

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	76	Engine Room No. 2 Wire			



From Power Source System (See Page 92)



## Service Hints

## Luggage Room J/B ECU

17. 18—Ground : Always approx. 12 volts  
 8—Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)  
 15. 21—Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	D5	C 67	J25	B 71
A18	66	F14	C 67	J26	71
C15	66	G1	67	R8	72
C16	A 66	J8	A 68	R9	72
C17	B 66	J9	B 68	W5	A 73
D3	A 67	J24	A 71	W6	B 73

## □ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)



## □ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
2F	27	Engine Room Main Wire and Engine Room J/B No.2 (Engine Compartment Left)
4C		
4D		
4E	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4K		
SD		
5G	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
DA	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD	34	Floor No.2 Wire and Driver Side J/B (Cowl Side Left)
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
LA	54	
LB		Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
LC	55	
LF		
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		
PK	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	78	Engine Room Main Wire and Floor No.2 Wire (Left Cowl Side Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
II2	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BJ1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)

# 转向信号和应急警告灯





## 转向信号和应急警告灯


### ▽ : Ground Points

Code	See Page	Ground Points Location
EA	76	Front Side of Front Right Fender Apron
EC	76	Rear Side of the Front Right Fender Apron
ED	76	Front Side of Front Left Fender Apron
EE	76	Rear Side of the Front Left Fender Apron
EF		
IK	76	Cowl Side Panel LH
IL	76	Left Side of Shift Lever
BQ	82	Rear Floor Partition Panel LH


### ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	76	Engine Room No.2 Wire			

# 车内灯



# F14(C), F15(D) Front Passenger's Side J/B ECU







# 车内灯

F14C1, F14D1  
Front Passenger's Side J/B ECU

- 1. w/ Smart Entry & Start System
- 2. w/o Smart Entry & Start System
- 3. Shielded



F14C1, F14D1  
Front Passenger's Side J/B ECU




# 车内灯

F14CL F15D1  
Front Passenger's Side J/B ECU


- 1: w/ Smart Entry & Start System
- 2: w/o Smart Entry & Start System

D 3AL D 3ICL D 4ID1  
Driver Side J/B ECU




F14CL F15D1  
Front Passenger's Side J/B ECU

D 3AL D 3ICL D 4ID1  
Driver Side J/B ECU




# 车内灯

F14CJ, F14SD  
Front Passenger's & Side JIB ECU




• 1. w/ Smart Entry & Start System

F14CJ, F14SD  
Front Passenger's Side JIB ECU




# 车内灯

F14(C), F15(D)  
Front Passenger's Side JIB ECU





F14(C), F15(D)  
Front Passenger's Side JIB ECU



- \* 1: w/ Smart Entry & Start System
- \* 2: w/o Smart Entry & Start System

车内灯



## 车内灯

### Service Hints

**Driver Side J/B ECU**  
15-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

- 14-Ground : Always approx. 12 volts (Power SW type)
- 1, 8-Ground : Always continuity

### Front Passenger's Side J/B ECU

15-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

- 22-Ground : Approx. 12 volts with the ignition SW at ON or ACC position (Ignition SW type) or with the power SW at IG ON or ACC ON position (Power SW type)
- 4-Ground : Always continuity
- 2, 26-Ground : Always approx. 12 volts

### D19 Driver Door ECU

- 4, 6-Ground : Always approx. 12 volts
- 3-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)
- 1-Ground : Always continuity

### F17 Front Passenger Door ECU

- 4, 6-Ground : Always approx. 12 volts
- 3-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)
- 1-Ground : Always continuity

### R11 Rear Door LH ECU

- 4, 6-Ground : Always approx. 12 volts
- 3-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)
- 1-Ground : Always continuity

### R14 Rear Door RH ECU

- 4, 6-Ground : Always approx. 12 volts
- 3-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)
- 1-Ground : Always continuity

### Luggage Room J/B ECU

- 17, 18-Ground : Always approx. 12 volts
- 8-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)
- 15, 21-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A11	66	F11	67	K5	68
A18	66	F14	C 67	M2	71
C15	66	F15	D 67	M3	71
C16	66	F17	71	O3	71
C20	70	F32	74	P10	72
C21	70	F33	74	R11	72
C22	70	G1	67	R14	72
C23	70	J8	A 68	R25	72
D3	A 67	J9	B 68	S36	73
D5	C 67	J21	A 71	T13	69
D6	D 67	J22	B 71	T14	A 69
D8	70	J23	71		B 69
D9	70	J24	A 71	V4	73
D10	70	J25	B 71	V5	73
D11	70	J26	71	V6	73
D12	70	J27	A 74	V7	73
D15	70	J28	B 74	W4	A 65
D19	70	J29	A 74	W5	B 73
F10	67	J30	B 74		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room/R/B No.1 (Near the Front Right Suspension Tower)

# 车内灯

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	27	Engine Room Main Wire and Engine Room J/B No.2 (Engine Compartment Left)
4B		
4C		
4D		
4E		
4F	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4G		
4H		
4I		
4K		
4L		
4M		
5A		
5B		
5C	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5D		
5G		
5I		
DA	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD		
DJ	34	Floor No.2 Wire and Driver Side J/B (Cowl Side Left)
DL	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
LA	54	Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
LC	55	
LF		
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		
PJ	40	Floor Wire and Front Passenger's Side J/B (Cowl Side Right)
PK	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	78	Instrument Panel Wire and Roof Wire (Left Side of the Instrument Panel)
IA2		
IC1	78	Front Door LH Wire and Floor No.2 Wire (Left Kick Panel)
IC2		
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IE1	78	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
IH1	80	Front Door RH Wire and Floor Wire (Right Kick Panel)
IH2		
IZ	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)
IL1	80	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IM1	80	Instrument Panel Wire and Floor No.2 Wire (Under the Rear Console)
BA1	82	Front Door LH Wire and Front Door LH No.2 Wire (Inside of the Front Door LH)
BD1	82	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BE1	82	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BJ1	84	Floor Wire and Floor No.2 Wire (Rear Floor Partition Panel RH)

## ▽ : Ground Points

Code	See Page	Ground Points Location
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH
BO	82	Under the Driver's Seat
BP	82	Under the Front Passenger's Seat
BQ	82	Rear Floor Partition Panel LH
BR	82	Rear Floor Partition Panel RH

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B1	84	Roof Wire			