

## BLACK SCREEN (NO IMAGE APPEARS ON NAVIGATION AND AUDIO SCREEN)

### INSPECTION PROCEDURE

#### 1 CHECK DISPLAY SETTING

- (a) Check that the display is not in "Screen OFF" mode.

**OK: The display setting is not in "Screen OFF" mode.**

NG

**CHANGE SCREEN TO "SCREEN ON" MODE**

OK

#### 2 CHECK IMAGE QUALITY SETTING

- (a) Check if screen color quality can be set.

**OK: Switching is possible.**

OK

**PRESS PANEL SWITCH "DISPLAY" AND SET SCREEN COLOR QUALITY TO NORMAL**

NG

#### 3 CHECK CABIN

- (a) Check if condensation is likely to occur, or the temperature is high or low (extremely cold) in the cabin.  
HINT:

This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.

**OK: The above condition is not observed.**

NG

**SET CABIN TEMPERATURE TO APPROPRIATE DEGREES**

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1873)**