


DTC	P0A95	HIGH VOLTAGE FUSE
------------	--------------	--------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
P0A95	Voltage between VBB9 and VBB10 terminals is below standard in spite of interlock switch being engaged (1 trip detection logic)	<ul style="list-style-type: none"> • High voltage fuse • Service plug grip • Battery plug • Battery ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

CAUTION:

- Before inspecting the high-voltage system, take safety precautions to prevent electrical shocks, such as wearing insulated gloves and removing the service plug grip. After removing the service plug grip, put it in your pocket to prevent other technicians from reconnecting it while you are servicing the high-voltage system.
- After disconnecting the service plug grip, wait at least for 5 minutes before touching any of the high-voltage connectors or terminals.

HINT:

At least 5 minutes is required to discharge the high-voltage condenser inside the inverter.

1	READ OUTPUT DTC(DTC P0A1F IS OUTPUT)
----------	---


- (a) Connect the hand-held tester or the OBD II scan tool to the DLC3.
- (b) Turn the power switch ON (IG).
- (c) Turn the hand-held tester or the OBD II scan tool ON.
- (d) On the hand-held tester, enter the following menus: DIAGNOSIS / ENHANCED OBD II / HV BATTERY / DTC INFO / TROUBLE CODES.
For the OBD II scan tool, see its instruction manual.
- (e) Read DTCs.

Result: DTC P0A1F is output

YES	REPLACE BATTERY ECU ASSY (See page 21-98)
------------	---

NO

2 INSPECT SERVICE PLUG GRIP



CAUTION:

Wear insulated gloves before performing the following operation.

- (a) Turn the power switch OFF.
- (b) Remove the service plug grip (see page 21-116).

NOTICE:

Turning the power switch ON (READY) with the service plug grip removed could cause malfunction. Therefore, never turn the power switch ON (READY) in this state.


- (c) Check the resistance between the terminals of the service plug grip.

Standard: Below 1 Ω

NG → Go to step 4

OK

3 INSPECT BATTERY PLUG



CAUTION:

Wear insulated gloves and goggles before performing the following operation.

- (a) Remove the HV battery assembly (see page 21-54).
- (b) Remove the battery plug (see page 21-77).
- (c) Check the resistance between the terminals of the battery plug.

Standard:


Tester Connection	Specified Condition
A – C	Below 1 Ω
B – D	Below 1 Ω

- (d) Reinstall the battery plug (see page 21-77).
- (e) Reinstall the HV battery assembly (see page 21-54).

NG → REPLACE BATTERY PLUG

OK

REPLACE BATTERY ECU ASSY (See page 21-98)

4 INSPECT HIGH VOLTAGE FUSE**CAUTION:**

Wear insulated gloves before performing the following operation.

(a) Remove the high voltage fuse (see page [21-116](#)).

HINT:

The high voltage fuse is enclosed in the service plug grip.

(b) Check the resistance between the terminals of the high voltage fuse.

Standard: Below 1 Ω

(c) Reinstall the high voltage fuse.

NG**REPLACE HIGH VOLTAGE FUSE****OK****REPLACE SERVICE PLUG GRIP**