

THE CELLULAR PHONE CANNOT SEND/RECEIVE

INSPECTION PROCEDURE

1 CHECK THE BLUETOOTH SETTINGS

(a) Check if the BLUETOOTH settings are correct.

OK: BLUETOOTH settings are correct.

NG

SET SETTINGS CORRECTLY

OK

2 CHECK CELLULAR PHONE

(a) Check if the cellular phone is BLUETOOTH capable.

HINT:

Some versions of BLUETOOTH capable cellular phone may not be compatible.

OK: The phone is BLUETOOTH capable.

NG

END (ONLY A BLUETOOTH CAPABLE CELLULAR PHONE CAN BE USED)

OK

3 CHECK SETTINGS

(a) Check if the cellular phone functions.

HINT:

- The cellular phone is unable to call under any of the following conditions.
- The cellular phone is locked.
- The directory is being transferred.
- The line is crossed.
- Transmission is regulated.
- The power is off.
- An emergency call is being made (LEXUS LINK SYSTEM is in operation).
- The cellular phone is not connected to BLUETOOTH ("BT" is displayed while a connection is present).

OK: None of the above conditions exists.

NG

SET SETTINGS CORRECTLY

OK

4 CHECK CELLULAR PHONE

(a) Check if the cellular phone can call.

HINT:

When the battery charge is low, calls cannot be made or received.

OK: The cellular phone can call.

NG

REPLACE THE CELLULAR PHONE

OK

5 CHECK RECEPTION

(a) Put a cellular phone into a receiving state.

(b) Place the cellular phone close to the multi-display.

(c) Check if the cellular phone has reception according to the multi-display.

OK: The cellular phone has reception.

NG

**REPLACE MULTI-DISPLAY
(SEE PAGE 67-7)**

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1873)**