

DTC	P0A94/585	DC/DC CONVERTER PERFORMANCE
------------	------------------	------------------------------------

CIRCUIT DESCRIPTION

Refer to DTC P0A94 (INF 589) on page [05-754](#).

DTC No.	INF Code	DTC Detection Condition	Trouble Area
P0A94	585	Boost converter voltage (VL) sensor performance problem	<ul style="list-style-type: none"> • Wire harness or connector • w/ converter inverter assembly

MONITOR DESCRIPTION

The HV control ECU monitors the boost converter voltage sensor signal. If the HV control ECU detects an abnormality in the sensor signal, it illuminates the MIL and sets a DTC.

MONITOR STRATEGY

Related DTCs	P0A94 (INF 585): Boost converter/Voltage (VL) sensor deviation
Required sensor/components	Boost converter, inverter, battery ECU
Frequency of operation	Continuous
Duration	TOYOTA's intellectual property
MIL operation	Immediately
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not present	TOYOTA's intellectual property
Other conditions belong to TOYOTA's intellectual property	–

TYPICAL MALFUNCTION THRESHOLDS

Boost converter voltage sensor	Abnormal
--------------------------------	----------

COMPONENT OPERATING RANGE

Boost converter	DTC P0A94 (INF 585) is not detected
-----------------	-------------------------------------

WIRING DIAGRAM

Refer to DTC P0A94 (INF 589) on page [05-754](#).

INSPECTION PROCEDURE

CAUTION:

- Before inspecting the high-voltage system, take safety precautions to prevent electrical shocks, such as wearing insulated gloves and removing the service plug grip. After removing the service plug grip, put it in your pocket to prevent other technicians from reconnecting it while you are servicing the high-voltage system.
- After disconnecting the service plug grip, wait at least for 5 minutes before touching any of the high-voltage connectors or terminals.

HINT:

At least 5 minutes is required to discharge the high-voltage condenser inside the inverter.

1	READ OUTPUT DTC(HV ECU)
----------	--------------------------------

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the power switch ON (IG).
- (c) Turn the hand-held tester ON.
- (d) On the hand-held tester, enter the following menus: DIAGNOSIS / ENHANCED OBD II / HV ECU / DTC INFO / TROUBLE CODES.
- (e) Read DTCs.

Result: DTC P0A94 (INF 585) and other DTCs are output

HINT:

If any other codes besides P0A94 (INF 585) are output, perform troubleshooting for those DTCs first.

YES	GO TO RELEVANT DTC CHART (See page 05-440)
------------	---

NO

2	CHECK HARNESS AND CONNECTOR(HYBRID VEHICLE CONTROL ECU – INVERTER)
----------	---



CAUTION:

Wear insulated gloves before performing the following operation.

- (a) Turn the power switch OFF.
- (b) Remove the service plug grip (see page [21-116](#)).

NOTICE:

Turning the power switch ON (READY) with the service plug grip removed could cause malfunction. Therefore, never turn the power switch ON (READY) in this state.



- (c) Disconnect the H16 HV control ECU connector.
- (d) Remove the inverter cover (see page 21-23).
- (e) Disconnect the I10 inverter connector.
- (f) Turn the power switch ON (IG).

HINT:

DTCs for the interlock switch system are output when turning the power switch ON (IG) with both service plug grip and inverter cover removed.

- (g) Measure the voltage between the terminals of the HV control ECU connector and body ground.

Standard:

Tester Connection	Specified Condition
VL (H16-30) – Body ground	Below 1 V
GCNV (H16-8) – Body ground	Below 1 V

- (h) Turn the power switch OFF.
- (i) Check the resistance between the wire harness side connectors.

Standard (Check for open):

Tester Connection	Specified Condition
VL (H16-30) – VL (I10-15)	Below 1 Ω
GCNV (H16-8) – GCNV (I10-32)	Below 1 Ω

Standard (Check for short):

Tester Connection	Specified Condition
VL (H16-30) or VL (I10-15) – Body ground	10 kΩ or higher
GCNV (H16-8) or GCNV (I10-32) – Body ground	10 kΩ or higher

- (j) Reconnect the inverter connector.
- (k) Reconnect the HV control ECU connector.
- (l) Reinstall the inverter cover (see page 21-23).
- (m) Reinstall the service plug grip (see page 21-116).

NG	REPAIR OR REPLACE HARNESS OR CONNECTOR
-----------	---

OK

REPLACE W/CONVERTER INVERTER ASSY (See page 21-23)