05.157.04

| DTC | B1210 | POWER SOURCE CONTROL ECU COMMUNICATION STOP |
|-----|-------|---|
|-----|-------|---|


CIRCUIT DESCRIPTION

This DTC is detected when communication between the power source control ECU and gateway ECU stops for more than 10 seconds.

| DTC No. | DTC Detection Condition | Trouble Area | |
|---------|--|---|--|
| B1210 | Power source control ECU communication stops | Power source control ECU Wire harness | |

2004 Prius - Preliminary Release (RM1075U)

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK OPERATION

(a) Without depressing the brake pedal, push the power switch repeatedly. Check that the power modes change between OFF, ON (ACC) and ON (IG) alternately.


OK: Smart indicator illuminates or starts blinking according to power modes.

NG \

Go to PUSH BUTTON START SYSTEM (See page 05-2429)

OK

2 CHECK WIRE HARNESS (POWER SOURCE CONTROL ECU – BODY GROUND)



- (a) Disconnect the P6 ECU connector.
- (b) Measure the resistance and voltage of the wire harness side connector.

Standard:


| Tester Connection | Condition | Specified Condition |
|------------------------------|---------------------|------------------------------------|
| P6-34 (IG1D) - | Power switch | |
| Body ground | 1: OFF → 2: ON (IG) | 1: 0 V \rightarrow 2: 10 to 14 V |
| P6–33 (AM1) – Body ground | Constant | 10 to 14 V |
| P6–6 (GND2) – Body ground | Constant | Below 1 Ω |

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

3 CHECK RESISTANCE OF COMMUNICATION LINE



- (a) Disconnect the P6 and G1 ECU connectors.
- (b) Disconnect the C10 meter connector.
- (c) Measure the resistance between the wire harness side connectors.

Standard:

| Tester Connection | Specified Condition | |
|-----------------------------|---------------------|--|
| P6-7 (MPX1) - C10-25 (MPX-) | Below 1 Ω | |
| P6-24 (MPX2) - G1-3 (MPD1) | Below 1 Ω | |

Result:

| Result | Proceed to |
|-------------|------------|
| Both are OK | А |
| One is OK | В |
| Both are NG | С |

В

REPLACE POWER SOURCE CONTROL ECU AND REPAIR OR REPLACE HARNESS AND CONNECTOR

C \

REPAIR OR REPLACE HARNESS AND CONNECTOR

A

REPLACE POWER SOURCE CONTROL ECU