

47. CHECK FOR ENGINE OIL LEAKS
48. CHECK FOR EXHAUST GAS LEAKS
49. INSPECT IGNITION TIMING (See page [EM-1](#))
50. INSPECT ENGINE IDLING SPEED (See page [EM-2](#))
51. INSPECT COMPRESSION (See page [EM-3](#))
52. INSPECT CO/HC (See page [EM-4](#))
53. INSTALL NO. 1 ENGINE COVER (See page [EM-43](#))
54. INSTALL FRONT FENDER APRON RH
55. INSTALL NO. 1 ENGINE UNDER COVER
56. INSTALL FRONT WHEEL RH
57. INSTALL RADIATOR SUPPORT OPENING COVER

## REPAIR

### 1. REPAIR VALVE SEATS

- (a) If the seating is too high on the valve face, use 30° and 45° cutters to correct the seat.
- (b) If the seating is too low on the valve face, use 75° and 45° cutters to correct the seat.

#### Standard width

Item	Standard Condition
Intake	1.0 to 1.4 mm (0.0394 to 0.0551 in.)
Exhaust	1.2 to 1.6 mm (0.0427 to 0.0630 in.)

- (c) Lap the valve and valve seat by hand with an abrasive compound.
- (d) Recheck the valve seating position.

EM

