


- (b) Remove the gasket from the exhaust manifold.



P

A126831

## INSTALLATION


### 1. INSTALL FRONT EXHAUST PIPE ASSEMBLY

- (a) Using a vernier caliper, measure the free length of the compression spring.


**Minimum length:**

**41.5 mm (1.634 in.)**

If the length is less than the minimum, replace the compression spring.



A077857E03



H

A133205E01

- (b) Install a new gasket by hand so that its surface is flush with the exhaust manifold.


**NOTICE:**

- **Make sure the gasket is facing the correct direction.**
- **Do not reuse the removed gasket.**
- **Do not push in the gasket while installing the front exhaust pipe.**

- (c) Install the front exhaust pipe with the 2 compression springs and 2 bolts.

**Torque: 43 N\*m (438 kgf\*cm, 32 ft.\*lbf)**

EX




P

A126831

**2. INSTALL CENTER EXHAUST PIPE ASSEMBLY**

- (a) Install a new gasket onto the front exhaust pipe.
- (b) Connect the 3 exhaust pipe supports, and install the center exhaust pipe.
- (c) Install the 2 bolts.


**Torque: 43 N\*m (438 kgf\*cm, 32 ft.\*lbf)**



P


A127754

**EX**



P

A126832




### 3. INSTALL TAILPIPE ASSEMBLY

- (a) Using a vernier caliper, measure the free length of the compression spring.

**Minimum length:**

**38.5 mm (1.516 in.)**


If the length is less than the minimum, replace the compression spring.



- (b) Install a new gasket by hand so that its surface is flush with the center exhaust pipe.

**NOTICE:**

- **Make sure the gasket is facing the correct direction.**
  - **Do not reuse the removed gasket.**
  - **Do not push in the gasket while installing the tailpipe.**
- (c) Connect the 2 exhaust pipe supports, and install the tailpipe.
- (d) Install the 2 compression springs and 2 bolts.  
**Torque: 43 N\*m (438 kgf\*cm, 32 ft.\*lbf)**



4. **INSTALL HEATED OXYGEN SENSOR (for Bank 1 Sensor 2) (See page EC-24)**

5. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**

6. **CHECK FOR EXHAUST GAS LEAKS**

If gas is leaking, tighten the areas necessary to stop the leak. Replace damaged parts as necessary.