

ON-VEHICLE INSPECTION

1. CHECK FUEL PUMP OPERATION

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch ON.

NOTICE:

Do not start the engine.

- Select the following tester menus: DIAGNOSIS, ENHANCED OBD II, ACTIVE TEST and FUEL PUMP/SPD. Operate the fuel pump.
- Touch the fuel hose in the engine compartment to check the fuel flow, and you will be able to hear the sound of the fuel pump.
- Stop the fuel pump. If there is no fuel flow, the fuel pump may not be operating. Check the fuel pump circuit.

2. CHECK FUEL PRESSURE

- Check that the battery positive voltage is above 12 V.
- Perform the "DISCHARGE FUEL SYSTEM PRESSURE" procedures (see page [FU-1](#)).
- Disconnect the cable from the negative (-) battery terminal.
- Disconnect the fuel main tube (see page [FU-22](#)).
- Install SST (pressure gauge) using SST and a fuel tube connector as shown in the illustration.

SST 09268-41048 (90467-13001, 95336-08070, 09268-41500), 09268-45014 (09268-41200, 09268-41220, 09268-41250)

- Wipe up any gasoline.
- Reconnect the cable to the negative (-) battery terminal.
- Start the engine.
- Measure the fuel pressure at idle.

Standard fuel pressure:

304 to 343 kPa (3.1 to 3.5 kgf/cm², 44.1 to 49.7 psi)

- If the fuel pressure is greater than the standard value, replace the fuel pump.
- If the fuel pressure is less than the standard value, check the connection of the fuel hose and the fuel pump.


- Stop the engine.
- Check that the fuel pressure remains as specified for 5 minutes after the engine stops.

Standard fuel pressure:

147 kPa (1.5 kgf/cm², 21 psi) or more

If the fuel pressure is not as specified, check the fuel pump or fuel injector.

- After checking the fuel pressure, carefully disconnect the negative (-) battery cable, and remove SST and fuel tube connector to prevent gasoline from splashing.
- Reconnect the fuel main tube (see page [FU-29](#)).



(n) Check for fuel leaks.