

DTC	B1412/12	Ambient Temperature Sensor Circuit
------------	-----------------	---


DESCRIPTION

The ambient temperature sensor is installed in the front part of the condenser to detect the ambient temperature and control the air conditioner. The sensor is connected to the combination meter and detects fluctuations in the ambient temperature. This data is used for controlling the room temperature. The sensor sends a signal to the air conditioning amplifier via the combination meter. The resistance of the ambient temperature sensor changes in accordance with the ambient temperature. As the temperature decreases, the resistance increases. As the temperature increases, the resistance decreases.

The air conditioning amplifier applies a voltage (5 V) to the ambient temperature sensor and reads voltage changes as changes in the resistance of the ambient temperature sensor. The combination meter sends the read signal to the air conditioning amplifier via CAN communication.

DTC No.	DTC Detection Condition	Trouble Area
B1412/12	Open or short in ambient temperature sensor circuit	<ul style="list-style-type: none"> Ambient temperature sensor Harness and connector between ambient temperature sensor and combination meter Combination meter Air conditioning amplifier CAN communication line

WIRING DIAGRAM



INSPECTION PROCEDURE

1	READ VALUE OF INTELLIGENT TESTER (AMBI TEMP SENS)
----------	--

- (a) Connect the intelligent tester (with CAN VIM) to the DLC3.

- (b) Turn the ignition switch ON and turn the intelligent tester main switch ON.
- (c) Select the item below in the DATA LIST, and read the value displayed on the intelligent tester.


Air conditioning amplifier

Item	Measurement Item / Display (Range)	Normal Condition	Diagnostic Note
AMBI TEMP SENS	Ambient temperature sensor / Min.: -23.3°C (-9.94°F) Max.: 65.95°C (150.71°F)	Actual ambient temperature is displayed	Open circuit: -23.3°C (-9.94°F) Short circuit: 65.95°C (150.71°F)

OK:
The display is as specified in the normal condition column.

Result

Result	Proceed to
NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C




2 INSPECT AMBIENT TEMPERATURE SENSOR

- (a) Remove the ambient temperature sensor.
- (b) Measure the resistance of the sensor.

Standard resistance

Tester Connection	Condition	Specified Condition
1 - 2	10°C (50°F)	3.00 to 3.73 kΩ
1 - 2	15°C (59°F)	2.45 to 2.88 kΩ
1 - 2	20°C (68°F)	1.95 to 2.30 kΩ
1 - 2	25°C (77°F)	1.60 to 1.80 kΩ
1 - 2	30°C (86°F)	1.28 to 1.47 kΩ
1 - 2	35°C (95°F)	1.00 to 1.22 kΩ
1 - 2	40°C (104°F)	0.80 to 1.00 kΩ
1 - 2	45°C (113°F)	0.65 to 0.85 kΩ
1 - 2	50°C (122°F)	0.50 to 0.70 kΩ
1 - 2	55°C (131°F)	0.44 to 0.60 kΩ
1 - 2	60°C (140°F)	0.36 to 0.50 kΩ



NOTICE:

- Touching the sensor even slightly may change the resistance value. Be sure to hold the connector of the sensor.
- When measuring, the sensor temperature must be the same as the ambient temperature.

HINT:

As the temperature increases, the resistance decreases (see the graph).

AC


NG

REPLACE AMBIENT TEMPERATURE SENSOR

OK

E114516E09

3 CHECK WIRE HARNESS (AMBIENT TEMPERATURE SENSOR - COMBINATION METER)



- (a) Disconnect the A17 sensor connector.
- (b) Disconnect the E19 meter connector.
- (c) Measure the resistance of the wire harness side connectors.

Standard resistance

Tester Connection	Specified Condition
A17-2 (OT+) - E19-23 (TEMP)	Below 1 Ω
A17-1 (OT-) - E19-11 (TX1+)	Below 1 Ω
A17-2 (OT+) - Body ground	1 M Ω or higher
A17-1 (OT-) - Body ground	1 M Ω or higher

NG **REPAIR OR REPLACE HARNESS AND CONNECTOR**

OK

REPLACE COMBINATION METER