DTC	C0210/33	Right Rear Wheel Speed Sensor Signal
DTC	C0215/34	Left Rear Wheel Speed Sensor Signal
DTC	C1238/38	Foreign Object is Attached on Tip of Rear
DTO	04000/00	Foreign Object is Attached on Tip of Rear
DIC	C1239/39	Speed Sensor LH
DTC	C1273/73	(Test Mode DTC)
DTC	C1274/74	Low Output Signal of Rear Speed Sensor LH (Test Mode DTC)
		Abnormal Change in Output Signal of Peer
DTC	C1277/77	Speed Sensor RH (Test Mode DTC)
	-	
DTC	C1278/78	Abnormal Change in Output Signal of Rear Speed Sensor LH (Test Mode DTC)

DESCRIPTION

BC

Refer to DTC C0200/31 (see page BC-62).

DTCs C1273/73, C1274/74, C1277/77 and C1278/78 can be deleted when the speed sensor sends a vehicle speed signal or the test mode ends. DTCs C1273/73, C1274/74, C1277/77 and C1278/78 are output only in the test mode.

DTC No.	DTC Detection Condition	Trouble Area
C0210/33 C0215/34	 When one of following conditions is met: At vehicle speed of 10 km/h (6 mph) or more, open or short in sensor signal circuit continues for 1 second or more. Momentary interruption of sensor signal from abnormal wheel occurs 255 times or more. Open in speed sensor signal circuit continues for 0.5 seconds or more. With IG1 terminal voltage 9.5 V or more, sensor power supply voltage decreases for 0.5 seconds or more. 	 Skid control sensor (for 2WD) Rear speed sensor (for 4WD) Skid control sensor circuit (for 2WD) Rear speed sensor circuit (4WD) Sensor installation Foreign matter on sensor rotor
C1238/38 C1239/39	 When either condition below is met: 1. At vehicle speed of 20 km/h (12 mph) or more, noise in malfunctioning wheel sensor signal condition continues for 5 seconds or more. 2. At vehicle speed of 10 km/h (6 mph) or more, noise input occurs once per rotor rotation for 15 seconds or more. 	 Skid control sensor (for 2WD) Rear speed sensor (for 4WD) Skid control sensor circuit (for 2WD) Rear speed sensor circuit (for 4WD) Sensor installation
C1273/73 C1274/74	Detected only during test mode.	 Skid control sensor (for 2WD) Rear speed sensor (for 4WD) skid control sensor circuit (for 2WD) Rear speed sensor circuit (for 4WD) Sensor installation Foreign matter on sensor rotor

DTC No.	DTC Detection Condition	Trouble Area
C1277/77 C1278/78	Detected only during test mode.	 Skid control sensor (for 2WD) Rear speed sensor (for 4WD) Skid control sensor circuit (for 2WD) Rear speed sensor circuit (for 4WD) Sensor installation

HINT:

- DTC C0210/33 and C1238/38 relate to the skid control sensor RH.
- DTC C0215/34 and C1239/39 relate to the skid control sensor LH.

WIRING DIAGRAM



INSPECTION PROCEDURE

NOTICE:

1

Check the speed sensor signal in test mode after cleaning or replacement (see page BC-28).

(a) Using the DATA LIST of the intelligent tester, check for any momentary interruption in the wire harness corresponding to a DTC (see page BC-23).

Skid control ECU

Item (Display)	Measurement Item / Range (Display)	Normal Condition	Diagnostic Note
RR SPD OPN Open	RR speed sensor open detection / ERROR or NORMAL	ERROR: Momentary interruption NORMAL: Normal	-
RL SPD OPN	RL speed sensor open detection / ERROR or NORMAL	ERROR: Momentary interruption NORMAL: Normal	-

HINT: Perform this inspection before removing the sensor and





ОК

2

READ VALUE OF INTELLIGENT TESTER (REAR SPEED SENSOR)

(a) Check the DATA LIST for proper functioning of the rear speed sensor.

Skid	control	ECU
------	---------	-----

Item (Display)	Measurement Item / Range (Display)	Normal Condition	Diagnostic Note
RR WHEEL SPD	Wheel speed sensor (RR) reading : min.: 0 km/h (0 mph), max.: 326 km/h (202.8 mph)	Similar to speed indicated on speedometer	-
RL WHEEL SPD	Wheel speed sensor (RL) reading : min.: 0 km/h (0 mph), max.: 326 km/h (202.8 mph)	Similar to speed indicated on speedometer	-

ЗC



(c) Drive the vehicle at a speed of 20 km/h (12 mph) or more for at least 60 seconds.

 (d) Check if the same DTC(s) is output (see page BC-47). Result

 Result
 Proceed to

 DTC is not output
 A

 DTC is output
 B

 B
 Go to step 11

END

Α



CHECK SKID CONTROL SENSOR OR REAR SPEED SENSOR (TIP)

- Remove the skid control sensor (for 2WD) or rear speed sensor (for 4WD).
- (b) Check the sensor tip. **OK:**

No scratches or foreign matter on the sensor tip.

CLEAR OR REPLACE SKID CONTROL SENSOR OR REAR SPEED SENSOR



6

7 CHECK WIRE HARNESS (SKID CONTROL ECU - REAR SPEED SENSOR)



- (a) Disconnect the A19 ECU connector.
- (b) Disconnect W1 and V1 sensor connectors for 2WD. Disconnect K23 and K22 sensor connectors for 4WD.
- (c) Measure the resistance of the wire harness side connectors.
 Standard resistance:

for 2WD (LH Side)

Tester Connection	Specified Condition
A19-20 (RL+) - W1-1 (RL+)	Below 1 Ω
A19-6 (RL-) - W1-2 (RL-)	Below 1 Ω
A19-20 (RL+) - Body ground	10 k Ω or higher
A19-6 (RL-) - Body ground	10 k Ω or higher

for 2WD (RH Side)

Tester Connection	Specified Condition
A19-5 (RR+) - V1-1 (RR+)	Below 1 Ω
A19-19 (RR-) - V1-2 (RR-)	Below 1 Ω
A19-5 (RR+) - Body ground	10 k Ω or higher
A19-19 (RR-) - Body ground	10 k Ω or higher

for 4WD (LH Side)

Tester Connection	Specified Condition
A19-20 (RL+) - K23-1 (RL+)	Below 1 Ω
A19-6 (RL-) - K23-2 (RL-)	Below 1 Ω
A19-20 (RL+) - Body ground	10 k Ω or higher
A19-6 (RL-) - Body ground	10 k Ω or higher

for 4WD (RH Side)

Tester Connection	Specified Condition
A19-5 (RR+) - K22-1 (RR+)	Below 1 Ω
A19-19 (RR-) - K22-2 (RR-)	Below 1 Ω
A19-5 (RR+) - Body ground	10 k Ω or higher
A19-19 (RR-) - Body ground	10 k Ω or higher

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

ОК



