

**DTC****C1337/37****Different Diameter Tire Malfunction****DESCRIPTION**

The skid control ECU measures the speed of each wheel by receiving signals from the speed sensor. These signals are used for recognizing that all 4 wheels are operating properly. Therefore, all wheel signals must be equal.

DTC No.	DTC Detection Condition	Trouble Area
C1337/37	With vehicle speed at 20 km/h (12 mph), condition that difference in average speed between front wheels and rear wheels is 20% or more continues for 20 seconds, and occurs consecutively 3 times each time the vehicle is driven.	Tire size

**INSPECTION PROCEDURE****1****CHECK TIRE SIZE**

- (a) Check the diameter of all 4 tires.

**OK:**

Diameter of all 4 tires are equal.

**NG****REPLACE TIRES WITH 4 EQUAL SIZE TIRES****OK****2****CHECK SPEED SENSOR ROTOR**

- (a) Remove the drive shaft, and check around the speed sensor rotor.

**OK:**

No scratches or foreign matter on the sensor tip.

**NG****REPLACE SPEED SENSOR ROTOR****OK****3****CHECK SPEED SENSOR**

- (a) Check the speed sensor circuit (see page [BC-64](#) or [BC-70](#)).

**NG****REPLACE SPEED SENSOR****OK****4****CHECK WIRE HARNESS (SKID CONTROL ECU - EACH SPEED SENSOR)**

- (a) Check the speed sensor circuit (see page [BC-69](#) or [BC-70](#)).

**NG****REPAIR OR REPLACE HARNESS AND CONNECTOR****OK****5****RECONFIRM DTC**

- (a) Clear the DTCs (see page [BC-47](#)).
- (b) Drive the vehicle at more than 20 km/h (12 mph) for more than 60 seconds.
- (c) Check if the same DTCs are detected.

**Result**

Result	Proceed to
DTC is output	A
DTC is not output	B

**B****END****A****REPLACE ABS AND TRACTION ACTUATOR ASSEMBLY****BC**