

No Answer-Back


DESCRIPTION

In some cases, wireless door lock control functions are normal but the hazard warning lights and / or wireless door lock buzzer answer-back function(s) is not operate. In such cases, the main body ECU's hazard warning lights and wireless door lock buzzer signal outputs may be malfunctioning.

NOTICE:

Troubleshooting should be started after confirming that the customize status of the answer-back function has been switched ON.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK WIRELESS DOOR LOCK CONTROL FUNCTION

- (a) Check the wireless door lock control functions by operating the transmitter switch.

Result:

Result	Proceed to
Wireless door lock functions are normal but hazard warning lights answer-back does not occur	A
Wireless door lock functions are normal but wireless door lock buzzer answer-back does not occur	B
Doors cannot be locked and unlocked with transmitter	C

B**Go to step 4****C****Go to FLOWCHART****A****2 PERFORM ACTIVE TEST BY INTELLIGENT TESTER (FLSH RELAY)**

- (a) Select the ACTIVE TEST, use the intelligent tester to generate a control command, and then check that the hazard warning lights flash.

Main body ECU:


Item	Test Details	Diagnostic Note
HAZARD	Turns FLSH relay ON / OFF	-

OK:**Hazard warning lights are turned ON / OFF.****OK****REPLACE INSTRUMENT PANEL JUNCTION BLOCK (MAIN BODY ECU)****NG****3 CHECK HAZARD WARNING LIGHT**

- (a) Check that the hazard warning lights flash continuously when the hazard warning signal switch is pressed.

OK:**Hazard warning lights flash continuously.****NG****Go to LIGHTING SYSTEM****OK****REPLACE INSTRUMENT PANEL JUNCTION BLOCK (MAIN BODY ECU)**

4 INSPECT WIRELESS DOOR LOCK BUZZER



- (a) Measure the resistance between terminals 1 and 2 of the buzzer.

Standard resistance:

Approximately 1 k Ω

NOTICE:


- The buzzer circuit is built into the body ECU, not into the buzzer itself.
- When battery voltage is directly applied to the buzzer, the buzzer does not sound.

NG

REPLACE WIRELESS DOOR LOCK BUZZER

OK

5 CHECK WIRE HARNESS (WIRELESS DOOR LOCK BUZZER - MAIN BODY ECU AND BODY GROUND)



- (a) Disconnect the A10 buzzer connector.
(b) Disconnect the E17 ECU connector.
(c) Measure the resistance of the wire harness side connectors.

Standard resistance

Tester Connection	Specified Condition
A10-1 - E17-2 (BZR)	Below 1 Ω
A10-2 - Body ground	
A10-1 or E17-2 (BZR) - Body ground	10 k Ω or higher

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

DL

REPLACE INSTRUMENT PANEL JUNCTION BLOCK (MAIN BODY ECU)