


Door LOCK Position Circuit

DESCRIPTION

This circuit detects the state of the door lock detection sensor and sends it to the main body ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER (DOOR LOCK POSITION)

- (a) Connect the intelligent tester (with CAN VIM) to the DLC3.
- (b) Turn the ignition switch to the ON position and press the intelligent tester main switch ON.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

Main body ECU


Item	Measurement item/Display (Range)	Normal Condition	Diagnostic Note
D LOCK POS SW	Driver's door lock position switch signal/ON or OFF	ON: Door lock is in unlock position OFF: Door lock is in lock position	-
P LOCK POS SW	Front passenger's door lock position switch signal/ON or OFF	ON: Front passenger's door lock is in unlock position OFF: Front passenger's door lock is in lock position	-

OK:
Condition sign can be displayed.

OK **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

NG

2 INSPECT FRONT DOOR LOCK



- (a) Remove the front door lock (driver side or passenger side).
- (b) Measure the resistance of the door lock.

Standard resistance:

Front door lock (for Driver Side)

Tester Connection	Condition	Specified Condition
8 (LSSR) - 7 (E)	LOCK	Below 1 Ω
	UNLOCK	10 kΩ or higher


Front door lock (for Passenger Side)

Tester Connection	Condition	Specified Condition
7 (LSSR) - 8 (E)	LOCK	Below 1 Ω
	UNLOCK	10 kΩ or higher

NG → **REPLACE FRONT DOOR LOCK ASSEMBLY**

OK

3 CHECK WIRE HARNESS (MAIN BODY ECU - DOOR LOCK AND BODY GROUND)



- (a) Disconnect the E15 main body ECU connector.
- (b) Measure the resistance of the wire harness side connector.

Standard resistance:
Front door lock (for Driver Side)

Tester Connection	Condition	Specified Condition
E15-25 (LSWD) - Body ground	LOCK	Below 1 Ω
	UNLOCK	10 kΩ or higher

Front door lock (for Passenger Side)

Tester Connection	Condition	Specified Condition
E15-10 (LSWP) - Body ground	LOCK	Below 1 Ω
	UNLOCK	10 kΩ or higher

NG → **REPAIR OR REPLACE HARNESS AND CONNECTOR**

OK

REPLACE INSTRUMENT PANEL JUNCTION BLOCK (MAIN BODY ECU)

