

DTC	B1790	Center Airbag Sensor Assembly Communication Circuit Malfunction
------------	--------------	--


DESCRIPTION

The center airbag sensor communication circuit consists of the occupant classification ECU and the center airbag sensor.

DTC B1790 is recorded when a malfunction is detected in the center airbag sensor communication circuit.

DTC No.	DTC Detection Condition	Trouble Area
B1790	When one of following conditions is met: <ul style="list-style-type: none"> • Occupant classification ECU detects line short circuit signal, open circuit signal, short circuit to ground signal or short circuit to B+ signal in the center airbag sensor assembly communication circuit for 2 seconds • Center airbag sensor malfunction • Occupant classification ECU malfunction 	<ul style="list-style-type: none"> • Floor wire • Occupant classification ECU • Center airbag sensor

WIRING DIAGRAM



RS

INSPECTION PROCEDURE

HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front passenger seat installation bolts to see the undersurface of the seat cushion.
- In the above case, hold the seat so that it does not tip over. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat up only for as long as necessary.

1 CHECK FOR DTC

- Turn the ignition switch ON.
- Clear the DTCs (see page [RS-249](#)).
HINT:
First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor.
- Turn the ignition switch OFF.
- Turn the ignition switch ON.
- Check the DTCs (see page [RS-249](#)).

OK:

DTC B1790 is not output.

HINT:

DTCs other than DTC B1790 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

2 CHECK CONNECTION OF CONNECTOR

- Turn the ignition switch OFF.
- Disconnect the cable from the negative (-) battery terminal, and wait for at least 90 seconds.
- Check that the connectors are properly connected to the occupant classification ECU and the center airbag sensor.

OK:


The connectors are properly connected.

NG

CONNECT CONNECTOR

OK

3 CHECK FLOOR WIRE (TO B+)




- (a) Disconnect the connectors from the occupant classification ECU and the center airbag sensor.
- (b) Connect the cable to the negative (-) battery terminal, and wait for at least 2 seconds.
- (c) Turn the ignition switch ON.
- (d) Measure the voltage of the wire harness side connector.

Standard voltage

Tester Connection	Specified Condition
L1-8 (FSR+) - Body ground	Below 1 V
L1-4 (FSR-) - Body ground	Below 1 V

NG REPAIR OR REPLACE FLOOR WIRE

OK

4 CHECK FLOOR WIRE (FOR OPEN)

- Turn the ignition switch OFF.
- Disconnect the cable from the negative (-) battery terminal, and wait for at least 90 seconds.
- Using a service wire, connect terminals L6-12 (FSP+) *1 and L6-13 (FSP-) *1 or L7-16 (FSP+) *2 and L7-24 (FSP-) *2 of connector B.

NOTICE:

Do not forcibly insert a service wire into the terminals of the connector when connecting them.

- Measure the resistance of the wire harness side connector.

Standard resistance


Tester Connection	Specified Condition
L1-8 (FSR+) - L1-4 (FSR-)	Below 1 Ω

HINT:

- *1: w/o Curtain shield airbag
*2: w/ Curtain shield airbag

NG**REPAIR OR REPLACE FLOOR WIRE****RS****OK**

5 CHECK FLOOR WIRE (FOR SHORT)



- (a) Disconnect the service wire from connector B.
- (b) Measure the resistance of the wire harness side connector.


Standard resistance

Tester Connection	Specified Condition
L1-8 (FSR+) - L1-4 (FSR-)	1 MΩ or higher

NG REPAIR OR REPLACE FLOOR WIRE

OK

6 CHECK FLOOR WIRE (TO GROUND)



- (a) Measure the resistance of the wire harness side connector.

Standard resistance

Tester Connection	Specified Condition
L1-8 (FSR+) - Body ground	1 MΩ or higher
L1-4 (FSR-) - Body ground	1 MΩ or higher

NG REPAIR OR REPLACE FLOOR WIRE

OK

RS

7

CHECK FOR DTC

- (a) Connect the connectors to the occupant classification ECU and the center airbag sensor.
- (b) Connect the cable to the negative (-) battery terminal, and wait for at least 2 seconds.
- (c) Turn the ignition switch ON.
- (d) Clear the DTCs (see page [RS-249](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor.

- (e) Turn the ignition switch OFF.
- (f) Turn the ignition switch ON.
- (g) Check the DTCs (see page [RS-249](#)).

OK:

DTC B1790 is not output.

HINT:

DTCs other than DTC B1790 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

8

REPLACE OCCUPANT CLASSIFICATION ECU

- (a) Turn the ignition switch OFF.
- (b) Disconnect the cable from the negative (-) battery terminal, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (see page [RS-392](#)).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

NEXT

9

PERFORM ZERO POINT CALIBRATION

- (a) Connect the cable to the negative (-) battery terminal, and wait for at least 2 seconds.
- (b) Connect the intelligent tester (with CAN VIM) to the DLC3.
- (c) Turn the ignition switch ON.
- (d) Using the intelligent tester, perform the zero point calibration (see page [RS-241](#)).

OK:

COMPLETED is displayed.

NEXT

10 PERFORM SENSITIVITY CHECK

- (a) Using the intelligent tester, perform the sensitivity check (see page [RS-241](#)).

Standard value:

27 to 33 kg (59.52 to 72.75 lb)

NEXT

11 CHECK FOR DTC

- (a) Turn the ignition switch ON.
(b) Clear the DTCs (see page [RS-249](#)).
HINT:
First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor.

- (c) Turn the ignition switch OFF.
(d) Turn the ignition switch ON.
(e) Check the DTCs (see page [RS-249](#)).

OK:

DTC B1790 is not output.

HINT:

DTCs other than DTC B1790 may be output at this time, but they are not related to this check.

NG

REPLACE CENTER AIRBAG SENSOR ASSEMBLY

OK

END

RS