


# UNDERDRIVE PLANETARY GEAR

## COMPONENTS

AX



N\*m (kgf\*cm, ft.\*lbf) : Specified torque


● Non-reusable part

## DISASSEMBLY

### 1. INSPECT UNDERDRIVE PLANETARY GEAR PRELOAD (See page AX-271)

### 2. REMOVE FRONT PLANETARY GEAR NUT


- (a) Using SST, loosen the staked part of the lock nut.  
**SST 09930-00010 (09931-00010, 09931-00020), 09387-00050**




- (b) Place the underdrive planetary gear in a soft jaw vise.

**NOTICE:**

**Be careful not to damage the differential drive pinion.**




- (c) Using a socket wrench, remove the lock nut.




### 3. REMOVE CYLINDRICAL ROLLER BEARING RACE INNER

- (a) Using SST, remove the cylindrical roller bearing race inner.

**SST 09950-00020, 09950-00030, 09950-60010 (09951-00320, 09957-04010)**






**4. REMOVE UNDERDRIVE PLANETARY GEAR ASSEMBLY**

- (a) Using SST and a press, press out the differential drive pinion, parking lock gear, counter driven gear with underdrive planetary ring gear and radial ball bearing front.


**SST 09950-60010 (09951-00320), 09387-00050, 09950-00020, 09950-00030, 09950-40011 (09957-04010)**

**AX**




- (b) Place the underdrive planetary gear in a soft jaw vise.
- (c) Using SST, remove the radial ball bearing rear from the underdrive planetary gear.

**SST 09950-60010 (09951-00320), 09950-00030, 09950-40011 (09957-04010)**




**5. REMOVE UNDERDRIVE PLANETARY RING GEAR**

- (a) Using snap ring pliers, remove the snap ring.



- (b) Remove the underdrive planetary ring gear from the counter driven gear.




**INSPECTION**

**1. INSPECT UNDERDRIVE PLANETARY GEAR PRELOAD**

- (a) Using SST, fix the underdrive planetary gear.

**SST 09387-00050**

AX



- (b) Using SST and a torque wrench, measure the turning torque of the underdrive planetary gear assembly while rotating the torque wrench at 60 rpm.


**SST 09387-00050**

**Torque: Standard turning torque at 60 rpm**

**0.50 to 1.42 N\*m (5.1 to 14.5 kgf\*cm, 4.4 to 12.6 in.\*lbf)**

## REASSEMBLY


### 1. INSTALL UNDERDRIVE PLANETARY RING GEAR




- (a) Install a new snap ring to the outer race of the radial ball bearing rear.

**HINT:**

When replacing the bearing, also replace the counter driven gear with a new one.



- (b) Using a piston ring compressor, squeeze the snap ring.




- (c) Using SST and a press, press in the outer race of the radial ball bearing rear.


**SST 09950-60020 (09951-00890), 09950-70010 (09951-07100)**

**NOTICE:**


**Be sure not to damage the snap ring during outer race installation.**



- (d) Install the underdrive planetary ring gear to the counter driven gear.



- (e) Using snap ring pliers, install the snap ring.




## 2. INSTALL UNDERDRIVE PLANETARY GEAR ASSEMBLY


- (a) Using SST and a press, press in the radial ball bearing rear to the underdrive planetary gear.  
**SST 09502-12010, 09950-60010 (09951-00260), 09950-70010 (09951-07100)**

### NOTICE:

**Press the bearing until it becomes flat at the bottom.**




- (b) Install the counter driven gear with planetary ring gear to the underdrive planetary gear.



- (c) Using SST and a press, press in the radial ball bearing front.  
**SST 09502-12010, 09950-60010 (09951-00260), 09950-70010 (09951-07100)**

### NOTICE:

**Press the counter driven gear while rotating it.**




- (d) Using SST and a press, press in the parking lock gear.  
**SST 09502-12010, 09950-60010 (09951-00260), 09950-70010 (09951-07100)**

### NOTICE:

**Press the counter driven gear while rotating it.**

AX




**3. INSTALL DIFFERENTIAL DRIVE PINION**

- (a) Using SST and a press, press in the differential drive pinion.

**SST 09726-40010, 09950-60010 (09951-00260), 09950-70010 (09951-07100)**

**NOTICE:**

- Check the position and number of the grooves on each end face of the differential drive pinion gear.
- Press the counter driven gear while rotating it.




**4. INSTALL CYLINDRICAL ROLLER BEARING RACE INNER**

- (a) Using SST and a press, press in the cylindrical roller bearing race inner.

**SST 09506-35010, 09950-60010 (09951-00260), 09950-70010 (09951-07100)**

**NOTICE:**

**Press the counter driven gear while rotating it.**



**5. INSTALL FRONT PLANETARY GEAR NUT**

- (a) Place the underdrive planetary gear in a soft jaw vise.

**NOTICE:**

**Be careful not to damage the differential drive pinion.**

- (b) Using a socket wrench, install a new lock nut.  
**Torque: 280 N\*m (2,885 kgf\*cm, 207 ft.\*lbf)**

- (c) Using a pin punch and hammer, stake the lock nut.

**NOTICE:**

**Be sure that there are no cracks on the nut.**

**6. INSPECT UNDERDRIVE PLANETARY GEAR PRELOAD (See page [AX-271](#))**

