



DISPOSAL

1. DISPOSE OF REAR SHOCK ABSORBER ASSEMBLY LH

- Fully extend the shock absorber rod, and clamp it in a vise at an angle.
- Using a drill, make a hole near the center of the cylinder in the hatched area shown in the illustration to discharge the gas inside.

CAUTION:

As metal debris may be blown outward by the gas, you must:

- Wear protective glasses.
- Cover the area being cut.

NOTICE:

The gas is colorless, odorless and harmless.