

INSTALLATION

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- 1. INSTALL FRONT DOOR BELT MOULDING ASSEMBLY LH
 - (a) Attach the claws to install the belt moulding. HINT: Confirm that the moulding is firmly installed.
- 2. INSTALL OUTER REAR VIEW MIRROR ASSEMBLY LH (See page MI-12)
- 3. INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH (See page ED-33)
- 4. INSTALL FRONT ARMREST BASE PANEL UPPER LH (See page ED-34)
- 5. INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH (See page ED-35)
- 6. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL