














# SUPPLEMENTAL RESTRAINT SYSTEM

## SST

|   |               |  |   |
|---|---------------|--|---|
|    | 09082-00700   | SRS Airbag Deployment Tool               | - |
|    | 09082-00750   | Airbag Deployment Wire Sub-harness No.3  | - |
|    | 09082-00780   | Airbag Deployment Wire Sub-harness No.6  | - |
|    | 09082-00802   | Airbag Deployment Wire Sub-Harness No. 8 | - |
|   | (09082-10801) | Wire A                                   | - |
|  | (09082-20801) | Wire B                                   | - |
|  | (09082-30801) | Wire C                                   | - |
|  | 09843-18060   | SRS Check Wire                           | - |
|  | 09950-50013   | Puller C Set                             | - |
|  | (09951-05010) | Hanger 150                               | - |
|  | (09952-05010) | Slide Arm                                | - |

|   |                      |                        |          |
|---|----------------------|------------------------|----------|
|  | <p>(09953-05020)</p> | <p>Center Bolt 150</p> | <p>-</p> |
|  | <p>(09954-05021)</p> | <p>Claw No.2</p>       | <p>-</p> |