

STEERING PAD SWITCH

DESCRIPTION

- A steering wheel with steering pad switches is standard equipment on all models. The frequently used switches are located on the steering pad for easy use.
- The switches that are provided on the steering pad vary by destination country and optional equipment, as indicated in the table below.

System	Switch	U.S.A.		CANADA
		With Navigation	Without Navigation	
Audio	<ul style="list-style-type: none"> • VOLUME (+/-) • MODE • SEEK (+/-) 	○	○	○
Air Conditioning	<ul style="list-style-type: none"> • AUTO • TEMP (+/-) • RECIRCULATION • Front DEF • Rear DEF 	○	○	○
Multi Display	Information	○	—	—
	Navigation			
	Telephone			
	<ul style="list-style-type: none"> • ON HOOK • OFF HOOK 			

System Diagram

