













# BRAKE


## PREPARATION

### SST



023GQ-01

	09023-00100	Union Nut Wrench 10 mm	REAR DRUM BRAKE BRAKE MASTER CYLINDER SUB-ASSY BRAKE ACTUATOR ASSY
	09214-76011	Crankshaft Pulley Replacer	SPEED SENSOR REAR LH
	09520-00031	Rear Axle Shaft Puller	SPEED SENSOR REAR LH
	(09520-00040)	Shocker	SPEED SENSOR REAR LH
	09521-00020	Drive Shaft Boot Clamping Tool	SPEED SENSOR REAR LH
	09703-30011	Tool Set, Brake Shoe Return Spring	REAR DRUM BRAKE
	09718-00010	Shoe Hold Down Spring Driver	REAR DRUM BRAKE
	09950-00020	Bearing Remover	SPEED SENSOR REAR LH
	09950-50013	Puller C Set	SKID CONTROL ECU ASSY STEERING SENSOR
	(09951-05010)	Hanger 150	SKID CONTROL ECU ASSY STEERING SENSOR
	(09952-05010)	Slide Arm	SKID CONTROL ECU ASSY STEERING SENSOR
	(09953-05020)	Center Bolt 150	SKID CONTROL ECU ASSY STEERING SENSOR

## PREPARATION - BRAKE

	(09954-05021) Claw No.2	SKID CONTROL ECU ASSY STEERING SENSOR
---	-------------------------	--

## Recommended Tools

	09042-00010 Torx Socket T30	BRAKE MASTER CYLINDER SUB-ASSY BRAKE ACTUATOR ASSY SKID CONTROL ECU ASSY STEERING SENSOR
	(09060-20010) Socket Wrench	SKID CONTROL ECU ASSY STEERING SENSOR

## Equipment

Stopwatch	
Dial indicator	
Radiator cap tester	
Torque wrench	
Voltmeter	
Dial indicator with magnetic base	
Tire pressure gauge	
Alignment tester	
Toe-in gauge	
Slide calipers	
Camber-caster-kingpin gauge	
Wheel balancer	
Drill	

## Lubricant

Item	Capacity	Classification
Brake fluid	-	SAE J1703 or FMVSS No. 116 DOT3