


















REAR SUSPENSION

PREPARATION



023HJ-01

SST

	09023-00100	Union Nut Wrench 10 mm	REAR AXLE BEAM ASSY
	09710-04101	Base	REAR AXLE BEAM ASSY
	09727-30021	Coil Spring Compressor	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727-00010)	Bolt Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727-00021)	Arm Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727-00031)	Compressor	REAR SHOCK ABSORBER WITH COIL SPRING
	09950-40011	Puller B Set	REAR AXLE BEAM ASSY
	(09951-04020)	Hanger 200	REAR AXLE BEAM ASSY
	(09952-04010)	Slide Arm	REAR AXLE BEAM ASSY
	(09953-04030)	Center Bolt 200	REAR AXLE BEAM ASSY
	(09954-04020)	Arm 100	REAR AXLE BEAM ASSY
	(09955-04051)	Claw No.5	REAR AXLE BEAM ASSY

	(09957-04010) Attachment	REAR AXLE BEAM ASSY
	(09958-04011) Holder	REAR AXLE BEAM ASSY
	09950-60010 Replacer Set	REAR AXLE BEAM ASSY
	(09951-00620) Replacer 62	REAR AXLE BEAM ASSY
	(09951-00630) Replacer 63	REAR AXLE BEAM ASSY

Recommended Tools

	09040-00011 Hexagon Wrench Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09043-20060) Socket Hexagon Wrench 6	REAR SHOCK ABSORBER WITH COIL SPRING

Equipment

Torque wrench	
Dial indicator with magnetic base	
Wheel balancer	
Tire pressure gauge	
Alignment tester	
Toe-in gauge	
Camber-caster-kingpin gauge	
Drill (Safety equipment: protective goggles, etc.)	Shock absorber disposal