

# BRAKE CONTROL WARNING LIGHT CIRCUIT (DOES NOT LIGHT UP)

## INSPECTION PROCEDURE

### 1 INSPECT CAN COMMUNICATION SYSTEM (SEE PAGE 05-2605)

(a) Is the DTC output for CAN communication system?

**Result:**

DTC is not output	A
DTC is output	B

**B**

**REPAIR CAN COMMUNICATION SYSTEM  
(SEE PAGE 05-2619)**

**A**

### 2 INSPECT MULTIPLEX COMMUNICATION SYSTEM (SEE PAGE 05-2549)

(a) Is the DTC output for Multiplex communication system?

**Result:**

DTC is not output	A
DTC is output	B

**B**

**REPAIR MULTIPLEX COMMUNICATION  
SYSTEM (SEE PAGE 05-2558)**

**A**

**REPAIR OR REPLACE COMBINATION METER ASSY (SEE PAGE 05-1986)**