


WASHER NOZZLE ADJUSTMENT

660HN-01

1. INSPECT WASHER NOZZLE

- (a) With the power switch on (IG), check the position that the washer fluid hits the windshield.

Standard: Washer fluid hits the windshield in the areas indicated in the illustration.



2. ADJUST WASHER NOZZLE

- (a) Using a TOYOTA 4 Way Nozzle Adjustment Tool (part number: 95060-10010), insert the bumpy portions of the adjustment tool into the bumpy portions of the nozzle jet and make the adjustment.

NOTICE:

- Clarify which type of washer nozzle is being adjusted, as two types (4 mm and 5 mm diameter types) exist.
- Do not use a metal pin or other such tool as it may damage the nozzle jet.

