


CRUISE CONTROL MAIN SWITCH REPLACEMENT

8204S-01

HINT:

Installation is in the reverse order of removal.

1. **PRECAUTION (SEE PAGE 60-1)**
2. **DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1)**
3. **REMOVE STEERING WHEEL COVER LOWER NO.2**
4. **REMOVE STEERING WHEEL COVER LOWER NO.3**
5. **REMOVE HORN BUTTON ASSY (SEE PAGE 60-20)**



6. **REMOVE CRUISE CONTROL MAIN SWITCH**
 - (a) Disconnect the connector.
 - (b) Remove the 2 screws and cruise control main switch.

7. **INSTALL HORN BUTTON ASSY (SEE PAGE 60-20)**
8. **CONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 19-2)**
9. **INSPECT HORN BUTTON ASSY (SEE PAGE 60-14)**
10. **INSPECT SRS WARNING LIGHT (SEE PAGE 05-1397)**
11. **PERFORM INITIALIZATION (SEE PAGE 01-28)**