

# 2004 PRIUS ELECTRICAL WIRING DIAGRAM

	Section Code	Page
INTRODUCTION .....	A .....	2
HOW TO USE THIS MANUAL .....	B .....	3
TROUBLESHOOTING .....	C .....	12
ABBREVIATIONS .....	D .....	17
GLOSSARY OF TERMS AND SYMBOLS .....	E .....	18
RELAY LOCATIONS .....	F .....	20
ELECTRICAL WIRING ROUTING .....	G .....	44
SYSTEM CIRCUITS .....	H .....	65
GROUND POINT .....	I .....	364
POWER SOURCE (Current Flow Chart) .....	J .....	370
CONNECTOR LIST .....	K .....	378
PART NUMBER OF CONNECTORS .....	L .....	390
OVERALL ELECTRICAL WIRING DIAGRAM .	M .....	394

©2003 TOYOTA MOTOR CORPORATION  
All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.