

2004 PRIUS

ELECTRICAL WIRING DIAGRAM

SYSTEM CIRCUITS

	Page
Air Conditioning	352
Audio System (Built-in Amplifier)	336
Audio System (Separate Amplifier)	326
Automatic Glare-Resistant EC Mirror	322
Automatic Light Control	160
Back-Up Light	186
Brake Control System	290
Clock	312
Combination Meter	342
Cruise Control	270
Door Lock Control	210
Engine Control	132
EPS	284
Front Fog Light	162
Front Wiper and Washer	198
Garege Door Opener	324
Headlight	148
Headlight Beam Level Control	156
Horn	310
Hybrid Vehicle Immobilizer System	82
Ignition	128
Illumination	178
Interior Light	170
Key Reminder	190
Light Auto Turn Off System	164
Luggage Compartment Door Opener	242
Mirror Heater	318
Multi-Display (Built-in Amplifier)	336
Multi-Display (Separate Amplifier)	326
Multiplex Communication System (AVC-LAN Bus)	78
Multiplex Communication System (BEAN Bus)	70
Multiplex Communication System (CAN Bus)	74
Power Outlet	314
Power Source	66
Power Window	206
Push Button Start System	82
Radiator Fan and Condenser Fan	348
Rear Window Defogger	318
Rear Wiper and Washer	202
Remote Control Mirror	316
Seat Belt Waning	194
Shift Control System	256
Smart Entry System	216
SRS	303
Stop Light	184
Taillight	178
Theft Deterrent	246
TOYOTA Hybrid System	96
Turn Signal and Hazard Warning Light	166
Wireless Door Lock Control (w/ Smart Entry System)	216
Wireless Door Lock Control (w/o Smart Entry System)	234