



FUEL PUMP
COMPONENTS



FU



FU

● Non-reusable part