


LOWER INSTRUMENT PANEL

PRECAUTION

1. PRECAUTION FOR VEHICLE WITH SRS AIRBAG AND SEAT BELT PRETENSIONER



- (a) Some operations in this section may affect the SRS airbags and seat belt pretensioner. Prior to performing the corresponding operations, read the SRS airbag NOTICE (see page [RS-1](#)).

COMPONENTS





IP

IP



N*m (kgf*cm, ft.*lbf) : Specified torque

NO. 1 INSTRUMENT PANEL
BRACKET COVER INNER RHNO. 1 INSTRUMENT PANEL
BRACKET COVER INNER LH

SHIFT LEVER KNOB

UPPER CONSOLE PANEL
SUB-ASSEMBLY




SWITCH BASE

UPPER REAR CONSOLE
PANEL SUB-ASSEMBLY


NO. 2 CONSOLE UPPER PANEL GARNISH




CONSOLE BOX CARPET

NO. 1 CONSOLE UPPER PANEL
GARNISH

CONSOLE CUP HOLDER BOX



REAR CONSOLE BOX SUB-ASSEMBLY

CONSOLE REAR END PANEL
(RSE Type)

CONSOLE REAR END PANEL



IP

STEREO JACK ADAPTER ASSEMBLY

