



REAR NO. 1 SEAT ASSEMBLY (for RH Side)

COMPONENTS

w/o Rear No. 2 Seat



w/o Rear No. 2 Seat

RECLINING REMOTE CONTROL LEVER
SUB-ASSEMBLY RH

REAR NO. 1 SEAT LOCK CABLE ASSEMBLY

REAR SHOULDER BELT HANGER

REAR NO. 1 SEAT OUTER BELT
ASSEMBLY RHRECLINING REMOTE CONTROL
LEVER BEZEL RH

ANCHOR COVER

42 (428, 31)

DECK TRIM SIDE PANEL ASSEMBLY RH

SIDE WINDOW
GARNISH HOOK


ROPE HOOK

N*m (kgf*cm, ft.*lbf) : Specified torque


TETHER ANCHOR BRACKET SUB-ASSEMBLY

T

SE



N*m (kgf*cm, ft.*lbf) : Specified torque



w/o Rear No. 2 Seat

REAR SEAT RECLINING
RELEASE LEVERREAR SEAT HEADREST
SUPPORTREAR SEATBACK LOCK
CONTROL LEVER BASE RH

REAR NO. 1 SEATBACK PAD

REAR NO. 1 SEATBACK COVER

● HOG RING

REAR SEAT COVER

REAR SEATBACK FRAME
SUB-ASSEMBLY RH

REAR SEATBACK PROTECTOR

REAR SEATBACK COVER RH

REAR SEAT RECLINING
ADJUSTER ASSEMBLY RH

N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

w/ Rear No. 2 Seat

