


SLIDING ROOF SYSTEM


PARTS LOCATION

SLIDING ROOF DRIVE GEAR SUB-ASSEMBLY
- SLIDING ROOF ECU




OCERHEAD JUNCTION BLOCK
-SLIDING ROOF CONTROL SWITCH

INSTRUMENT PANEL JUNCTION BLOCK
- MAIN BODY ECU



SYSTEM DIAGRAM



B130036E01

Communication table

Sender	Receiver	Signal	Line
Main Body ECU	Sliding Roof ECU	Key-off operation signal	LIN

RF