













SUPPLEMENTAL RESTRAINT SYSTEM


PREPARATION

023E6-01

SST

	09082-00700	SRS Airbag Deployment Tool	HORN BUTTON ASSY CURTAIN SHIELD AIRBAG ASSY FRONT SEAT AIRBAG ASSY FRONT PASSENGER AIRBAG ASSY
	09082-00750	Airbag Deployment Wire Sub-harness No.3	FRONT SEAT AIRBAG ASSY
	09082-00780	Airbag Deployment Wire Sub-harness No.6	HORN BUTTON ASSY FRONT PASSENGER AIRBAG ASSY
	09082-00802	Airbag Deployment Wire Sub-Harness No. 8	HORN BUTTON ASSY CURTAIN SHIELD AIRBAG ASSY FRONT PASSENGER AIRBAG ASSY
	(09082-10801)	Wire A	HORN BUTTON ASSY CURTAIN SHIELD AIRBAG ASSY FRONT PASSENGER AIRBAG ASSY
	(09082-20801)	Wire B	CURTAIN SHIELD AIRBAG ASSY
	(09082-30801)	Wire C	HORN BUTTON ASSY FRONT PASSENGER AIRBAG ASSY
	09950-50013	Puller C Set	SPIRAL CABLE SUB-ASSY
	(09951-05010)	Hanger 150	SPIRAL CABLE SUB-ASSY
	(09952-05010)	Slide Arm	SPIRAL CABLE SUB-ASSY
	(09953-05020)	Center Bolt 150	SPIRAL CABLE SUB-ASSY
	(09954-05021)	Claw No.2	SPIRAL CABLE SUB-ASSY

Recommended Tools

	09042-00010 Torx Socket T30	HORN BUTTON ASSY SPIRAL CABLE SUB-ASSY SEAT POSITION AIR BAG SENSOR
---	-----------------------------	---

Equipment

Torque wrench	
Feeler gauge	
Bolt Length: 35.0 mm (1.378 in.) Pitch: 1.0 mm (0.039 in.) Diameter: 6.0 mm (0.236 in.)	Airbag disposal
Tire Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Tire with disc wheel Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Plastic bag	Airbag disposal