

TORQUE SPECIFICATION

Part Tightened		N-m	kgf-cm	ft-lbf
Fuel deliver pipe sub-assy x Cylinder head sub-assy (See page 11-15)	Bolt A	19	194	14
	Bolt B	9.0	92	80 in.-lbf
Cylinder head cover sub-assy Cylinder head sub-assy		10	102	7
Ignition coil assy x Cylinder head cover sub-assy		9.0	92	80 in.-lbf
Engine wire x Cylinder head cover sub-assy		9.0	92	80 in.-lbf
Reservoir bracket x Body		8.5	87	75 in.-lbf
Brake master cylinder reservoir sub-assy x Reservoir bracket		8.5	87	75 in.-lbf
Cowl top panel sub-assy outer front x Body		6.4	65	57 in.-lbf
Trap w/ outlet valve canister assy x Fuel tank assy		6.0	61	53 in.-lbf
Fuel tank bracket RR x Fuel tank assy		6.0	61	53 in.-lbf
Fuel tank band sub-assy No. 1 RH x Body		39	400	29
Fuel tank band sub-assy No. 1 LH x Body		39	400	29
Exhaust pipe assy front x Exhaust manifold		43	440	32
Exhaust pipe assy front x Exhaust pipe assy tail		43	440	32