

## CASSETTE TAPE CANNOT BE EJECTED

### INSPECTION PROCEDURE

#### 1 | PRESS "EJECT" AND CHECK OPERATION

- (a) Press "EJECT" and check the operation.
- (1) Press the cassette tape EJECT switch of the radio receiver assembly for 2 seconds or more and check that the cassette tape is ejected.

**OK: The cassette tape is ejected.**

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-5)

OK

#### 2 | CHECK CASSETTE TAPE

- (a) Check the cassette tape.
- (1) Check that the ejected cassette tape does not have a peeled label, a cassette body deformation or any other defect.

**OK: No fault on the cassette tape.**

NG

CASSETTE TAPE IS FAULTY

OK

#### 3 | REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

- (a) Replace the cassette tape with another and recheck.
- (1) Replace the cassette tape with another normal one to see if the same trouble occurs again.

**OK: Malfunction disappears.**

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-5)

OK

CASSETTE TAPE IS FAULTY