

<b>DTC</b>	<b>P0A90/240</b>	<b>DRIVE MOTOR "A" PERFORMANCE</b>
------------	------------------	------------------------------------

### CIRCUIT DESCRIPTION

Refer to DTC P0A90 (INF 239) on page [05-663](#).

DTC No.	INF Code	DTC Detection Condition	Trouble Area
P0A90	240	Generator locked	• Hybrid vehicle generator

### INSPECTION PROCEDURE

If the information (INF) code is present, replace the hybrid vehicle generator.

<b>REPLACE HYBRID VEHICLE GENERATOR ASSY</b>
--