# NETWORK GATEWAY ECU

REPLACEMENT

6716Z–01

HINT:
- COMPONENTS: See page 67–2
- Installation is in the reverse order of removal.

1. REMOVE INSTRUMENT PANEL SUB–ASSY W/PASSENGER AIRBAG ASSY (SEE PAGE 71–7)

HINT:

Refer to the procedures up to "REMOVE INSTRUMENT PANEL SUB–ASSY W/ PASSENGER AIRBAG ASSY".

2. REMOVE NETWORK GATEWAY ECU
(a) Disconnect the connector.
(b) Remove the bolt and network gateway ECU.

3. INSTALL INSTRUMENT PANEL SUB–ASSY W/PASSENGER AIRBAG ASSY (SEE PAGE 71–7)

HINT:

Refer to the procedures from "INSTALL INSTRUMENT PANEL SUB–ASSY W/ PASSENGER AIRBAG ASSY".