

CD CANNOT BE EJECTED**INSPECTION PROCEDURE****1 | PRESS "EJECT" AND CHECK OPERATION**

(a) Press "EJECT" and check the operation.

- (1) Press the CD EJECT switch of the radio receiver assembly for 2 seconds or more to see if the CD is ejected.

OK: CD is ejected.

HINT:

If the CD is not ejected, bring the vehicle in for repair.

Do not attempt to remove it by force.

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-5)

OK

2 | REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the CD with another and recheck.

- (1) Check the installation condition of the radio receiver assembly.

OK: Installed properly.

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-5)

OK

CD IS FAULTY