

SOUND QUALITY IS BAD ONLY WHEN PLAYING TAPE

INSPECTION PROCEDURE

1 REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

- (a) Replace the cassette tape with another one and recheck.
- (1) Replace the cassette tape with another normal one to see if the same trouble occurs again.
OK: Malfunction disappears.

OK

CASSETTE TAPE IS FAULTY

NG

2 CHECK FOR ANY FOREIGN OBJECT


- (a) Check for foreign objects.
- (1) Check that no foreign objects or defects are detected in the cassette tape player.
OK: No foreign objects or defects are detected.

NG

REMOVE FOREIGN OBJECT

OK

3 CLEAN HEAD AND CHECK OPERATION



- (a) Head cleaning
- (1) Raise the cassette door with your finger. Using a pencil or similar object, push in the guide.
- (2) Using a cleaning pen or cotton applicator soaked in cleaner, clean the head surface, pinch rollers and capstans.
- (3) Check if the same trouble occurs again.
OK: Malfunction disappears.

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-5)

OK

HEAD IS DIRTY