



NAVIGATION CHECK MODE (MICROPHONE CHECK)

HINT:


- The microphone is checked in the "Navigation Check (Microphone Check)" mode.
 - Illustrations may differ from the actual vehicle depending on vehicle specifications.
1. **Start the diagnostic mode (see page 05-1881)**



2. **Select "Navigation Check" from "Diagnosis MENU".**



3. **Select "Microphone Check" from "Navigation Check".**



4. **Perform the microphone check by following the directions on the "Microphone Check" screen.**