POWER DOOR LOCK CONTROL SYSTEM

PRECAUTION

05.136-01

NOTICE FOR INITIALIZATION:

When disconnecting the negative (–) battery terminal, initialize the following system(s) after the terminal is reconnected.

System Name	See Page
Power Window Control System	05–2028

NOTICES FOR HYBRID SYSTEM ACTIVATION:

When the warning lamp is illuminated or the battery has been disconnected and reconnected, pressing the power switch may not start the system on the first try. If so, press the power switch again.

2004 Prius - Preliminary Release (RM1075U)

Author: Date: 2234