

CURSOR OR MAP ROTATES WHEN VEHICLE IS STOPPED**INSPECTION PROCEDURE****1 CHECK CONDITION**

(a) Check with the customer if the vehicle has been turned by a turn-table at parking.

OK: The vehicle has not been turned by a turntable.

HINT:

If the power switch is turned to the ACC or ON position while the vehicle is being turned by a turntable, the system may store the angular velocity at this time. For this reason, the vehicle position cursor could deviate.

NG**TURN POWER SWITCH TO ON POSITION WHEN VEHICLE IS COMPLETELY STOPPED****OK****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1873)**