

VOICE ON PHONE CANNOT BE HEARD, TOO QUIET, OR DISTORTED

INSPECTION PROCEDURE

1 CHECK CELLULAR PHONE

- (a) Check if the voice on the other side can be heard using a cellular phone.

OK: Voice can be heard.

NG

REPLACE THE CELLULAR PHONE

OK

2 CHECK SETTINGS

- (a) Check if the volume is set to the minimum or maximum setting.

HINT:

When the volume is set to the minimum or maximum setting, the sound may be distorted.

- (b) Check if the MUTE switch is set to ON.

OK: MUTE switch is not set to ON.

NG

SET MUTE SWITCH CORRECTLY

OK

3 CHECK VOICE

- (a) Check if the navigation voice can be heard.

OK: The voice can be heard.

NG

GO TO "VOICE GUIDANCE DOES NOT FUNCTION" (SEE PAGE 05-1914)

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1873)**