

## HOW TO PROCEED WITH TROUBLESHOOTING

### HINT:

- Use this procedure to troubleshoot the multiplex communication system.
- The hand-held tester should be used in step 2.

### 1 VEHICLE BROUGHT TO WORKSHOP



### 2 DTC CHECK (See page 05-2557)

- Check for DTCs and note any codes that are output.
- Delete the DTC.
- Recheck for DTCs. Try to prompt the DTC by simulating the original activity that the DTC suggests.
  - If the DTC does not reoccur, proceed to A.
  - If the DTC reoccurs, proceed to B.

**B**

Go to step 4

**A**

### 3 OVERALL ANALYSIS AND TROUBLESHOOTING

- Terminals of ECU (see page 05-2550)

### 4 ADJUST, REPAIR OR REPLACE



### 5 CONFIRMATION TEST



**END**